


ELECTRIC SEATS



E164795



Do not adjust the seat while the vehicle is moving. Doing so could cause a loss of vehicle control and personal injury.

1. Cushion length adjustment.

2. Bolster adjustment (inflate/deflate).

3. Lumbar support adjustment.

- Press the top of the button to raise.