


MEDIA CONTROLS



E177656



In the interest of safety, only operate, adjust or view the system when it is safe to do so.



Sustained exposure to high sound levels (greater than 85 decibels) can damage your hearing.

1. Touch to select the Media system; or if the Media system is already switched on, touch to select the current media source.
2. Press to select the media **SOURCE** list. Touch the required media source from the list:
 - **FM Radio**
 - **AM Radio**
 - **DAB Radio**
 - **Bluetooth***
 - **USB***

- **iPod***
- **AUX**

***Note:** *Only a connected portable media or Bluetooth® device will appear on the Source list. Therefore, before selecting a device, the source media device has to be connected or paired (via Bluetooth) to the vehicle.*

3. Press to select the Media system.
4. Touch to select the **GENERAL SETTINGS** menu, followed by **Media**, to view the **MEDIA SETTINGS** screen. See **152, MEDIA SETTINGS**.
5. Press to switch the Media system on/off; rotate to adjust the volume level.