

Intelligent emergency braking	
ACC.....	143
Intelligent speed limiter (ISL).....	134
Intelligent speed limiter warning lamp.....	53
Intelligent stop/start	
activating.....	105
deactivating.....	105–106
Intelligent stop/start warning lamp.....	54
Interior cleaning.....	213
airbag covers.....	214
Interior lamps.....	60
ambient lighting.....	61
bulb changing.....	200
intensity.....	61
stealth mode.....	61
types.....	60
Interior locking.....	18
temporary disabling.....	15
Internet browsing	
InControl connection.....	173
Introduction	
instructional videos.....	3
Intrusion sensor.....	17
ISL warning lamp.....	53
ISOFIX and i-Size anchor points.....	38
J	
Jump starting	
connecting a starting aid.....	227
connecting jump leads.....	225
K	
Keyless entry.....	9
Keyless locking.....	15
Key transmitters.....	9
L	
Label locations.....	260
Lamps.....	56
auto lamps wiper detection.....	58
bulb changing.....	200
condensation.....	58
rear lamp removal.....	207
test.....	51
TPMS warning lamp.....	54
warning lamps.....	51
xenon headlamps.....	201
Lane departure warning.....	129
Lane departure warning lamp (green).....	54
Lane departure warning lamp (red).....	52
Lane drifting.....	130
Leather cleaning.....	213
Levelling	
headlamps.....	58
License	
navigation.....	182
Lighting	
ambient lighting.....	61
interior lamps intensity.....	61
interior lamps locations.....	60
stealth mode.....	61
Limp home mode.....	109
Load securing.....	89
Locking	
automatic relocking.....	14
confirmation.....	14
door locks and release levers.....	18
double locking.....	14
drive away.....	12
emergency locking.....	19
global closing.....	17
in an emergency.....	19
keyless.....	15
mislock.....	18
passive.....	16
single.....	14
transmitter effects on medical devices.....	9
with the emergency key.....	19
Locking wheel nuts.....	255
Low fuel warning lamp.....	53
Low oil pressure warning lamp.....	52
Lubricants specifications.....	263
Luggage compartment	
anchor points.....	89