

- trailer sway.....91
  - weights.....90
  - Towing eyes
    - front.....256
    - rear.....257
  - tracDSC
    - stability control.....111
  - Tracking your vehicle
    - InControl secure.....173
  - Traction control
    - switching between DSC and tracDSC.....111
    - switching off.....111
    - switching on.....112
    - tracDSC.....111
  - Traffic sign recognition.....131
  - Trailer
    - electrical connections.....95
    - sway.....91
    - towing weights.....90
  - Trailer direction indicators warning lamp.....55
  - Trailer tow assist.....91
  - Training
    - videos 9,56,79,145,152,156,161,164,171,174,180–182,189
  - Transmission
    - automatic.....107
    - gear shift warning lamp.....54
    - limp home mode.....109
    - manual.....109
  - Transmitters
    - smart key.....268
  - Transporting the vehicle.....256
  - Trip computer.....48
    - average speed.....48
    - fuel consumption.....48
    - fuel range.....49
    - reset.....48
    - trip distance.....49
  - Turning ACC follow mode off.....55
  - Tyre pressure checking after a repair.....248
  - Tyre pressure monitoring system (TPMS)..243
    - tyre care.....237
    - valves.....239
    - warning lamp.....54
  - Tyre pressures.....244
  - Tyre repair kit
    - checking pressures.....248
    - repair procedure.....247
    - safety information.....246
    - using.....247
  - Tyres
    - age degradation.....240
    - changing.....244
    - flat spots.....240
    - important information.....255
    - Indian regulations.....242
    - pressure check.....243
    - pressures.....238
    - recommended tyre pressure look-up.....244
    - repair kit.....246
    - repair kit use.....247
    - repair procedure.....247
    - replacements.....239
    - snow chains.....241
    - speed ratings.....237
    - temporary use spare.....244
    - TPMS.....243
      - warning lamp.....54
    - tyre care.....237
    - tyre repair safety.....246
    - tyre wall markings.....236
    - use of spare tyre.....255
    - valves.....239
    - vehicle loading.....244
    - wall markings.....236
    - winter.....240
- ## U
- Under bonnet covers.....199–200
  - Understeer.....111
  - Unlocking.....18
    - all doors.....6
    - driver's door.....6
    - entry and exit mode.....29
    - global opening.....6, 8
    - keyless entry.....9
    - luggage compartment.....10
    - mode.....6
    - multi point entry.....6, 8