

- tyre pressure monitoring system (TPMS).....54
 - Warning messages.....48
 - Washer jets.....215
 - Washer reservoir
 - capacity.....264
 - Washers.....62
 - fluid specification.....223
 - fluid top up.....223
 - headlamps.....64
 - Washing
 - automatic car wash.....212
 - exterior paintwork.....212
 - removing grease.....213
 - removing stains.....214
 - removing tar.....213
 - soft top.....213
 - Water in fuel.....190
 - Web browsing
 - InControl connection.....173
 - Weights
 - gross vehicle weights.....265
 - roof load.....265
 - roof rack weight.....265
 - tow ball/hitch.....90
 - towing.....90
 - vehicle weights.....265
 - Wheel changing
 - important information.....255
 - locking wheel nuts.....255
 - recommended process.....252
 - safety warnings.....250
 - spare wheel.....254
 - temporary spare wheel.....254
 - tilt sensor.....252
 - use of spare tyre.....255
 - Wheel chocks use.....254
 - Wheels and tyres
 - age degradation.....240
 - changing a tyre.....244
 - checking the pressures after a repair.....248
 - flat spots.....240
 - Indian regulations.....242
 - pressures.....238
 - puncture repair.....246
 - puncture repair safety.....246
 - repair kit.....246
 - repair kit use.....247
 - repair procedure.....247
 - replacements.....239
 - snow chains.....241
 - temporary use spare.....244
 - TPMS.....243
 - TPMS warning lamp.....54
 - tyre care.....237
 - tyre speed ratings.....237
 - tyre wall markings.....236
 - valves.....239
 - winter tyres.....240
 - Wheel spin.....111
 - Where to
 - navigation system.....180
 - Wi-Fi
 - InControl connection.....173
 - Windows
 - anti-trap protection.....73
 - operation.....72
 - reset.....210
 - side window blinds.....74
 - solar attenuating.....74
 - sunroof reset.....210
 - Winter park position.....209
 - Winter tyres.....240
 - Wipers.....62
 - Wipers and washers.....62
 - drip wipe.....64
 - fluid level.....222
 - rain sensor.....63
 - speed-dependent mode.....63
 - Wireless technology
 - Bluetooth.....163
- ## X
- Xenon headlamps.....201

