

- bulb changing.....200
- condensation.....58
- courtesy delay.....57
- daytime running lamps.....57
- driving abroad.....58
- halogen bulbs.....202
- high beam assist.....57
- high beam assist warning lamp.....54
- high beam warning lamp.....55
- levelling.....58
- warning lamp (AFS).....52
- washers.....64
- xenon.....201
- Head restraints
 - front seats.....26
 - rear seats.....26
- Head up display.....50
- Heated seats.....80
- Heated steering wheel.....29
- Heating and ventilation.....78
 - air quality sensor.....80
 - automatic recirculation.....80
 - front.....78
 - fuel burning heater.....81
 - heated and cooled seats.....80
 - heated seats.....80
 - rear.....85
 - remote control batteries.....84
 - timed climate remote controls.....83
 - using the remote control.....83
- Heating and ventilation settings.....79
- High beam assist.....57
- Hill start assist.....117
- Hitch guidance cameras.....91
- Homelink.....70
 - assistance.....71
 - erase all programming.....71
 - programming.....70
 - programming a single button.....71
 - programming the garage door opener.....70
- I**
- Ignition
 - rolling re-start.....103
 - switching on.....102
- InControl
 - apps.....174
 - overview.....169
 - protect.....169
 - remote premium.....171
 - secure.....173
 - wi-fi connection.....173
- Indicators warning lamp.....54
- Information messages.....48, 51
- Infotainment
 - connecting a media device.....156
 - connecting multiple devices.....159
 - licensing.....160
 - media controls.....151
 - pairing and connecting a device.....159
 - playing a portable device.....159
 - portable media
 - connections.....156
 - controls.....158
 - radio controls.....154–155
 - settings.....152
 - touch screen
 - care.....76
 - extra features.....77
 - operating.....76
- Instrument panel.....47, 215
 - display units.....49
 - fuel range.....49
 - head up display.....50
 - lamp test.....51
 - menu.....47
 - driving features.....47
 - instrument display.....47
 - trip computer.....47
 - vehicle set-up.....47
 - recommended tyre pressures.....244
 - service indicator.....49
 - trip computer.....48
 - trip distance.....49
 - tyre pressure check.....243
 - warning lamps.....51
 - warning messages.....48