

- Occupant safety
 - child seat tether straps.....39
 - recommended child seats.....37
 - seat belt checks.....32
 - seat belt pre-tensioners.....31
 - seat belt reminder warning.....33
 - seat belt safety.....31
 - seat belts warning lamp.....52
 - using seat belts.....30
- Octane rating.....186
 - petrol.....186
- Oil
 - engine oil specification.....219
 - filler locations.....216
 - specification.....263
 - top up.....219
 - used engine oil.....199
- Opening the bonnet.....199
- Oversteer.....111
- Overview
 - InControl mobile technology.....169
- Owner maintenance.....196
- P**
- Paddle shift.....109
- Paintwork
 - cleaning.....212
 - repair.....215
- Pairing a phone or device.....163
- Park assist.....124
 - cleaning sensors and cameras.....212
 - hands free parking.....123
 - limitations of use.....125
 - selecting.....124
 - troubleshooting.....125
- Park assist options.....124
- Parking aids
 - cleaning sensors and cameras.....212
 - operating.....118
 - rear camera.....119, 122
 - reverse traffic detection.....121
 - system fault.....119
- Parking brake.....116
 - warning lamp.....52
- Particle filter.....197
- Parts.....198
- Passenger compartment fuse box.....232
- Passive alarm arming.....16
- Passive entry.....9
- Passive locking.....16
- Pedestrian protection system.....258
 - after deployment.....258
- Perimeter alarm.....15
- Petrol
 - fuel types.....186
- Petrol consumption.....194
- Petrol filler flap.....191
- Phone
 - call volume.....167
 - deleting the connected phone or device..165
 - InControl.....171
 - overview.....166
 - safety.....167
 - steering wheel controls.....167
- Phone compatibility.....163
- Playing a portable device.....159
- Points of interest (POI).....181
- Polishing the bodywork.....213
- Portable media
 - Bluetooth wireless technology.....163
 - connections.....156
 - controls.....158
- Portable media pairing.....163
- Powered tow ball.....94
- Power sockets.....88
- Pressure checking (tyres)
 - checking after a repair.....248
- Pressures
 - tyres.....238
- Progress control
 - overview.....148
 - settings.....149
 - using the system.....148
- Progress control warning lamp.....54
- Puncture repair kit.....246
 - instructions for use.....247
 - repair procedure.....247
 - safety.....246