
Interior lights

INTERIOR LIGHTS



- 1. Front seat footwell lamps.
- 2. Glovebox lamp: Open to illuminate.
- **3.** Vanity mirror lamps: Lift the sun visor flap to illuminate.
- 4. Rear seat footwell lamps.
- **5.** Front reading lamps: Touch the lens briefly to switch on/off.
- **6.** Front interior courtesy lamp: Touch the lens briefly to switch on/off.
- 7. Rear interior courtesy lamp.
- 8. Rear reading lamps: Press the appropriate button to activate a reading lamp manually. Press again to switch off.