

Index

- diesel fuel.....187
- oil level.....217
- petrol fuels.....186
- running-in.....196
- specifications.....262
- starting
 - keyless start backup.....103
 - switching off.....102
- Engine/transmission warning lamp.....53
- Engine compartment
 - fluid filler locations.....216
- Engine compartment cleaning.....212
- Engine covers
 - refitting.....200
 - removal.....199
- Engine oil
 - capacity.....264
- Engine starting.....102
 - failure to start.....104
- Engine temperature warning lamp.....51
- Entering the vehicle
 - entry and exit mode.....29
 - global opening.....8
 - keyless entry.....9
 - luggage compartment.....10
 - passive entry.....9
 - tailgate operation.....10
 - unlocking mode.....8
- Ethanol.....186
- Event data recording.....258
- Exhaust filter.....197
- Exhaust fluid
 - diesel.....188
- Exiting the vehicle
 - arming the alarm.....19
 - closing mislock.....18
 - door locks and release levers.....18
 - double locking.....14
 - emergency locking.....19
 - full alarm.....15
 - global closing.....17
 - interior locks.....18
 - keyless locking.....15
 - lock confirmation.....14
 - passive arming.....16
 - passive locking.....16
 - perimeter alarm.....15
 - single locking.....14
- Exterior cleaning.....212
- Exterior lamps
 - bulb changing.....200
- Exterior mirrors
 - electric.....65
 - manual.....65
 - mirror dip when reversing.....66
- External temperature
 - warning lamp.....53
- Extinguisher.....211
- Extra features.....77
- F**
- Fatigue alert.....130
- Fire extinguisher.....211
- Flat spots.....240
- Fluids
 - brake
 - check.....221
 - specification.....222
 - top up.....222
 - capacities.....264
 - clutch check.....221
 - coolant
 - specification.....220
 - top up.....220
 - engine oil
 - check.....217
 - filler locations.....216
 - oil
 - top up.....219
 - specifications.....263
 - washer fluid.....223
 - check.....222
 - specification.....223
- Fog lamps
 - warning lamps
 - rear.....54
- Follow
 - override.....139