

- A**
- About this handbook.....2
 - Accessories.....193
 - Active differential control.....76
 - Adaptive cruise control.....83
 - ACC gap change.....84
 - automatic switch-off.....85
 - driving hints.....86
 - follow mode.....83
 - forward alert.....87
 - intelligent emergency braking.....88
 - malfunction.....87
 - queue assist.....85
 - radar detection beam issues.....86
 - resume follow mode.....85
 - resume set speed.....85
 - set speed and follow mode override.....84
 - Adaptive dynamics.....78
 - Adaptive front lighting system.....50
 - warning lamp.....45
 - Adaptive headlamps.....50
 - AdBlue®.....185
 - After a collision
 - pedestrian protection system.....241
 - Age degradation (tyres).....229
 - Airbags
 - active head restraints.....35
 - cover cleaning.....202
 - curtain.....37
 - deployment.....36, 38
 - disability modifications.....39
 - front.....37
 - locations.....35
 - maintenance.....193
 - obstruction.....36
 - service information.....38
 - side.....37
 - warning lamp.....38, 46
 - Air conditioning
 - air quality sensor.....138
 - automatic recirculation.....138
 - front.....136
 - Alarm.....10, 193
 - automatic relocking and arming.....11
 - battery backed sounder.....11
 - deactivating.....11
 - passive arming.....11
 - perimeter.....11
 - security sensor fault.....12
 - tilt sensor.....11
 - All surface progress control.....97–98
 - Anchor points (luggage).....67
 - Anti-lock braking system (ABS) warning lamp.....45
 - Anti-theft system.....193
 - Anti-trap protection
 - sunroof.....62
 - windows.....62
 - Approach lamps.....50
 - Arduous driving conditions.....195
 - Audible warnings.....48
 - Audio
 - AM/FM radio controls.....114
 - automatic station retune.....115
 - CD loading.....109
 - changing portable media device.....123
 - conversation assist.....110
 - DAB radio
 - controls.....116
 - settings.....117
 - dual view.....130
 - dual view controls.....130
 - end user licensing agreement.....110
 - full screen view.....125
 - licensing.....112
 - media controls.....107
 - portable media connections.....118
 - portable media controls.....120
 - portable media pairing.....122
 - portable media playing.....121
 - steering wheel controls.....108
 - TV controls.....126
 - Auto lamps
 - wiper detection.....50
 - Automatic locking.....6, 11
 - Automatic speed limiter
 - warning lamp.....46

- Automatic switch off of ACC.....85
- Automatic transmission.....74
 - gear selector.....75
 - gear shift warning lamp.....47
 - shift paddles.....75
 - temporary manual selection.....75
- Auto zoom (navigation).....169
- Auxiliary device connection.....122
- Auxiliary power sockets.....64

- B**
- Battery
 - boost starting.....214
 - care.....212
 - charging.....215
 - connecting jump leads.....213
 - disconnecting jump leads.....214
 - luggage compartment access with a discharged battery.....68
 - maintenance.....212
 - replacing.....215
 - using a starting aid.....214
 - warning lamp.....45
 - warning symbols.....212
- Battery backed sounder.....11
- Blinds.....61
 - rear window.....60
- Blind spot monitor
 - closing vehicle sensing.....94
 - displayed messages.....95
 - notification of overtaking vehicle.....93
 - sensor blockage.....95
- Bluetooth
 - compatibility.....157
 - general information.....161
 - pairing
 - via the phone.....157
 - phone
 - icons.....158
 - safety.....157
 - portable media
 - pairing.....122
 - playing.....121
- Bluetooth phone
 - call volume.....159
 - overview.....156
 - steering wheel controls.....159
- Bonnet
 - closing.....195
 - opening.....195
- Booster seats for larger children.....32
- Boost starting.....214
- Brakes
 - ABS warning lamp.....45
 - electronic brake force distribution.....79
 - emergency assist.....88
 - emergency brake assist.....79
 - fluid check.....208
 - fluid specification.....209
 - fluid top up.....209
 - handbrake.....80
 - high level brake lamp.....197
 - hill start assist.....79
 - important information.....79
 - parking brake warning lamp.....45
 - warning lamp (amber).....45
 - warning lamp (red).....44
- Breakdown assistance
 - InControl link.....179
- Bulbs
 - changing a bulb.....196
 - rear lamps.....197

- C**
- Cameras
 - proximity view.....153
 - single rear camera.....152
 - touch screen menu.....153
- Capacities.....249
 - engine oil.....249
 - fuel tank.....249
 - washer reservoir.....249
- Carpets and mats.....202
- Car-wash.....199
- CD/DVD
 - loading discs.....109

Index

- CD player
 - portable media pairing.....122
 - portable media playing.....121
- Cell phone
 - call volume.....159
 - icons.....158
 - overview.....156
 - steering wheel controls.....159
- Cell phone safety.....157
- Changing a bulb.....196
- Changing a fuse.....216
- Changing a wheel
 - locking wheel nuts.....239
 - recommended process.....238
 - safety warnings.....237
- Charging the vehicle battery.....215
- Chassis number.....243
- Child safety
 - booster seats.....32
 - check list.....32
 - child seats.....28
 - ISOFIX installation.....32
 - larger children on booster seats.....32
 - lock and window inhibitor.....28
 - positioning.....29
 - recommended child seats.....31
 - tether straps.....33
- Cleaning
 - airbag covers.....202
 - alloy wheels.....199
 - automatic car wash.....199
 - carpets and mats.....202
 - engine compartment.....199
 - exterior.....199
 - paintwork.....199
 - glass.....199
 - interior.....200–201
 - leather.....200
 - park assist sensors.....199
 - parking aids sensors.....199
 - polishing.....200
 - rear screen.....200
 - removing grease.....200
 - removing stains.....201
 - removing tar.....200
 - seat belts.....202
 - sensors and cameras.....199
 - sunroof.....200
 - using a car-wash.....199
 - washer jets.....196
 - wipers.....202
- Cleaning the wiper blades.....202
- Climate control
 - automatic recirculation.....138
 - climate seats.....142
 - front.....136
 - heated seats.....141
 - rear.....139
 - seat comfort.....141
- Clock.....40
- Closing
 - luggage compartment.....65
- Closing the bonnet.....195
- Closing vehicle sensing.....94
- Commandshift.....74
- Condensation (headlamps).....51
- Conformity declarations.....252
- Connecting jump leads.....213
- Connectivity
 - connecting a sim card.....178
 - settings.....177
 - status icons.....178
- Controls cleaning.....200
- Convenience mode.....7
- Coolant
 - checking the level.....207
 - specification.....208
 - top up.....208
- Covers
 - refitting.....196
 - removal.....196
- Critical warning messages.....44
- Cruise control.....82
 - ACC driving hints.....86
 - ACC emergency braking.....88
 - ACC follow mode.....83
 - ACC gap change.....84
 - ACC radar detection beam issues.....86

- ACC set speed and follow mode
 - override.....84
 - adaptive cruise control.....83
 - adaptive cruise control malfunction.....87
 - follow mode.....83
 - forward alert in ACC.....87
 - resume ACC follow mode.....85
 - resume ACC set speed.....85
 - using ACC.....83
 - warning lamp.....47
- Curtain airbags.....37
- D**
- DAB radio
 - settings.....117
- DAB radio controls.....116
- Data recording.....241
- Daytime running lamps.....49
- Declarations of conformity.....252
- DEF.....185
- Detection beam issues.....86
- Diesel
 - filler flap.....188
 - fuel.....185
 - glow plugs
 - warning lamp.....46
 - misfuel device.....188
 - sulphur content.....185
 - water in fuel.....187
- Diesel engines.....187
- Diesel particulate filter (DPF).....194
 - sulphur content.....185
- Differential control.....76
- Dimensions.....247
- Direction indicators.....49
 - warning lamp.....47
- Disability modifications
 - airbags.....39
- Displays.....201
- Door mirrors.....56
 - blind spot monitor.....93
 - closing vehicle sensing.....94
 - sensors.....95
- Door transceiver
 - assistance.....59
 - erase all programming.....59
 - programming.....58
 - programming a single button.....59
 - programming the garage door opener.....58
- Double locking.....9
 - full alarm.....10
- DPF.....194
- Drive away locking.....6
- Driver exit
 - deactivating intelligent stop/start.....73
- Driving
 - ACC automatic switch-off.....85
 - ACC driving hints.....86
 - ACC emergency braking.....88
 - ACC follow mode.....83
 - ACC forward alert.....87
 - ACC gap change.....84
 - ACC malfunction.....87
 - ACC queue assist.....85
 - ACC radar detection beam issues.....86
 - ACC set speed and follow mode
 - override.....84
 - activating intelligent stop/start.....72
 - active differential.....76
 - adaptive cruise control.....83
 - after a collision.....241
 - after deployment of the pedestrian protection system.....241
 - arduous conditions.....195
 - automatic speed limiter.....81
 - before starting.....241
 - blind spot monitor.....93
 - closing vehicle sensing.....94
 - blind spot monitor messages.....95
 - brakes important information.....79
 - daily checks.....194
 - deactivating intelligent stop/start.....72
 - DSC active warning lamp.....46
 - electronic brake force distribution.....79
 - emergency brake assist.....79
 - forward alert.....87
 - forward alert warning lamp.....47

- gear shift warning lamp.....47
- hill start assist.....79
- low oil pressure.....44
- progress control settings.....98
- progress control system overview.....97
- rain sensor.....55
- resume ACC follow mode.....85
- resume ACC set speed.....85
- running-in.....193
- sitting correctly.....15
- using ACC.....83
- using cruise control.....82
- using the progress control system.....97
- weekly checks.....194
- Driving abroad
 - beam pattern.....51
 - headlamps.....51
- Driving aids
 - traffic sign recognition.....92
- Driving modes.....90
 - dynamic program.....90
 - winter.....90
- Driving position memory.....14
 - recalling a position.....15
- Dual view.....130
 - controls.....130
- Dynamic program.....90
- Dynamic stability control (DSC).....76
 - DSC active warning lamp.....46
 - DSC off warning lamp.....46
 - switching between DSC and tracDSC.....76
 - switching off.....76
 - switching on.....76
- E**
- Electric parking brake.....80
- Electric seats.....13
 - head restraints.....19
 - position memory.....14
 - recalling a memory position.....15
 - restricted seat travel.....15
- Electric windows
 - operation.....60
- Electronic brake force distribution.....79
- Electronic data.....241
- Emergency brake assist.....79, 88
- Emergency call
 - InControl link.....179
- Emergency key locking.....12
- Emergency release
 - luggage compartment.....67
- Engine
 - antifreeze level.....207
 - compartment opening.....195
 - coolant level.....207
 - diesel.....187
 - diesel fuel.....185
 - oil level.....205
 - petrol fuels.....184
 - running-in.....193
 - specifications.....244
 - starting
 - keyless start backup.....71
 - switching off.....70
- Engine/transmission warning lamp.....45
- Engine compartment
 - fluid filler locations.....203
- Engine compartment cleaning.....199
- Engine covers
 - refitting.....196
 - removal.....196
- Engine oil
 - capacity.....249
- Engine starting.....70
 - failure to start.....71
- Engine temperature warning lamp.....44
- Entering the vehicle
 - entry and exit mode.....22
 - global opening.....6
 - keyless entry.....6
 - passive entry.....6
- Ethanol.....184
- Event data recording.....241
- Executive class rear seats.....16
 - massage.....17
 - passenger seat away.....14
- Exhaust filter.....194

Exhaust fluid	
diesel.....	185
Exiting the vehicle	
arming the alarm.....	12
closing mislock.....	10
door locks and release levers.....	9
double locking.....	9
emergency locking.....	12
full alarm.....	10
global closing.....	10
interior locks.....	9
keyless locking.....	10
lock confirmation.....	9
passive arming.....	11
perimeter alarm.....	11
single locking.....	9
Exterior cleaning.....	199
Exterior lamps	
bulb changing.....	196
Exterior mirrors	
electric.....	56
manual.....	56
mirror dip when reversing.....	57
External temperature	
warning lamp.....	46
Extinguisher.....	198
F	
Fire extinguisher.....	198
First aid kit.....	198
Flat spots.....	229
Fluids	
brake	
check.....	208
specification.....	209
top up.....	209
capacities.....	249
coolant	
specification.....	208
top up.....	208
engine oil	
check.....	205
filler locations.....	203
oil	
top up.....	207
power steering	
check.....	209
specification.....	210
top up.....	210
specifications.....	245
washer fluid.....	211
check.....	210
specification.....	211
Fog lamps	
warning lamps	
rear.....	46
Folding table.....	17
Follow	
override.....	84
Follow mode	
entering.....	83
gap change.....	84
gap changing.....	84
override.....	85
resume.....	85
Forward alert.....	87
Forward alert in ACC	
object detection.....	87
Forward alert warning lamp.....	47
Front airbags.....	37
Front climate control	
automatic recirculation.....	138
Front wipers	
winter park position.....	197
Fuel and refuelling.....	188
consumption.....	190
diesel.....	185
diesel fuel sulphur content.....	185
ethanol.....	184
filler flap.....	188
fuel filler flap.....	188
methanol.....	185
methyl tertiary butyl ether (MTBE).....	185
misfuel device.....	188
octane rating.....	184
petrol.....	184
running out.....	187

Index

safety precautions.....	184
tank capacity.....	189
water in fuel.....	187
Fuel can.....	187
Fuel consumption.....	190
combined cycles.....	192
extra-urban cycle.....	192
urban cycle.....	192
Fuel filler flap.....	188
Fuel gauge.....	40
Fuel system.....	195
Fuel tank	
capacity.....	249
Full screen view for video.....	125
Fuses	
changing.....	216
engine compartment fuse box.....	218
locations.....	216
luggage compartment fuse box.....	223
passenger compartment fuse box.....	220

G

Garage door opener.....	58
assistance.....	59
erase all programming.....	59
programming.....	58
programming a single button.....	59
Garage door transceiver.....	58
Gearbox	
automatic.....	74
gear shift warning lamp.....	47
identification number.....	243
limp home mode.....	75
Glass cleaning.....	199
Global closing.....	10
Global opening.....	6
Glow plugs	
warning lamp.....	46

H

Handbook symbols.....	2
Handbrake.....	80
Headlamps.....	49

adaptive.....	50
approach lamps.....	50
beam pattern.....	51
bulb changing.....	196
condensation.....	51
daytime running lamps.....	49
driving abroad.....	51
high beam assist.....	50
high beam assist warning lamp.....	47
high beam warning lamp.....	47
warning lamp (AFS).....	45
washers.....	55
xenon.....	196

Head restraints

active.....	35
electric seats.....	19
front seats.....	19
rear seats.....	20
removing.....	21

Heated steering wheel.....

Heating and ventilation

air quality sensor.....	138
automatic recirculation.....	138
climate seats.....	142
front.....	136
heated seats.....	141
rear.....	139

High beam assist.....

Hill start assist.....

Homelink.....

assistance.....	59
erase all programming.....	59
programming.....	58
programming a single button.....	59
programming the garage door opener.....	58

I

Identifying the vehicle

transmission number.....	243
--------------------------	-----

Ignition

rolling re-start.....	71
switching on.....	70

InControl

apps.....	182
-----------	-----

- connected navigation.....171
 - connectivity.....177
 - overview.....179
 - pro services.....182
 - protect.....179
 - remote premium.....180
 - secure.....181
 - Indicators warning lamp.....47
 - Information messages.....41, 44
 - Infotainment
 - audio settings.....109
 - loading discs.....109
 - Infotainment
 - automatic station retune.....115
 - connecting a media device.....119
 - DAB radio
 - settings.....117
 - DAB radio controls.....116
 - deploying the rear seat screens.....133
 - dual view.....130
 - controls.....130
 - DVD player controls.....128
 - full screen view.....125
 - headphones.....132
 - importing/ripping media.....123
 - media controls.....107
 - media player controls.....124
 - portable media
 - changing.....123
 - connecting multiple devices.....122
 - connections.....118
 - controls.....120
 - pairing.....122
 - playing.....121
 - radio controls.....114
 - touch screen
 - care.....101
 - extra features.....104
 - home menu.....100
 - my home screen.....102
 - operating.....101
 - TV controls.....126
 - Instrument panel.....40, 201
 - display units.....43
 - fuel range.....42
 - lamp test.....44
 - menu.....41
 - driving features.....41
 - instrument display.....41
 - trip computer.....41
 - vehicle set-up.....41
 - recommended tyre pressures.....232
 - service indicator.....43
 - trip computer.....42
 - trip distance.....42
 - tyre pressure check.....231
 - warning lamps.....44
 - warning messages.....41
 - Intelligent emergency braking
 - ACC.....88
 - Intelligent stop/start
 - activating.....72
 - deactivating.....72–73
 - warning lamp.....46
 - Intelligent stop/start warning lamp.....47
 - Interior cleaning.....200–201
 - airbag covers.....202
 - carpets and mats.....202
 - Interior lamps.....52
 - bulb changing.....196
 - types.....52
 - Interior locking.....9
 - Intrument panel menu
 - navigation information.....171
 - ISOFIX installation.....32
- ## J
- Jump starting
 - connecting a starting aid.....214
 - connecting jump leads.....213
 - disconnecting jump leads.....214
- ## K
- Keyless entry.....6
 - Keyless locking.....10

- L**
- Label locations.....243
 - Lamps.....49
 - auto lamps wiper detection.....50
 - brake lamp.....197
 - bulb changing.....196
 - bulb replacement.....196
 - condensation.....51
 - rear lamp removal.....197
 - test.....44
 - TPMS warning lamp.....47
 - warning lamps.....44
 - xenon headlamps.....196
 - Leather cleaning.....200
 - Licensing
 - audio/video.....110
 - Lighting
 - interior lamps locations.....52
 - Limp home mode.....75
 - Load securing.....67
 - Loadspace
 - emergency release.....67
 - Locking
 - automatic relocking.....11
 - confirmation.....9
 - door locks and release levers.....9
 - double locking.....9
 - drive away.....6
 - emergency locking.....12
 - global closing.....10
 - in an emergency.....12
 - keyless.....10
 - mislock.....10
 - security sensor fault.....12
 - single.....9
 - with the emergency key.....12
 - Locking wheel nuts.....239
 - Low fuel warning lamp.....46
 - Low oil pressure warning lamp.....44
 - Lubricants specifications.....245
 - Luggage compartment
 - access with a discharged battery.....68
 - anchor points.....67
 - closing.....65
 - emergency release.....67
 - opening.....65
 - opening height.....66
- M**
- Maintenance
- arduous driving conditions.....195
 - brake fluid level.....208
 - bulb changing.....196
 - rear lamp removal.....197
 - capacities.....249
 - changing a fuse.....216
 - checking tyre pressure after a repair.....235
 - cleaning
 - alloy wheels.....199
 - exterior.....199
 - glass.....199
 - interior.....200–201
 - leather.....200
 - rear screen.....200
 - seat belts.....202
 - sensors and cameras.....199
 - the engine compartment.....199
 - closing the bonnet.....195
 - daily checks.....194
 - disconnecting jump leads.....214
 - engine compartment fuse box.....218
 - engine coolant level.....207
 - engine oil level.....205
 - fuel system.....195
 - fuse box (passenger compartment).....220
 - jump starting.....214
 - label locations.....243
 - lubricants and fluid specifications.....245
 - luggage compartment access with a
 - discharged battery.....68
 - luggage compartment fuse box.....223
 - oil top up.....207
 - paintwork repair.....199
 - polishing.....200
 - power steering fluid level.....209
 - removing grease and tar.....200
 - removing stains.....201

- running-in.....193
- side window blind reset.....198
- smart key battery.....7
- sunroof wind deflector.....200
- tyre repair kit.....233
- tyre repair procedure.....234
- using a starting aid.....214
- washer fluid level.....210
- weekly checks.....194
- Manual seats
 - head restraints.....19
- Map
 - auto zoom.....169
 - split screen.....168
 - updates.....170
- Massage seats.....142
- Media
 - audio settings.....109
 - automatic station retune.....115
 - conversation assist.....110
 - DVD player controls.....128
 - end user licensing agreement.....110
 - licensing.....112
 - loading discs.....109
 - media controls.....107
 - portable media
 - connecting a media device.....119
 - importing/ripping media.....123
 - radio controls.....114
 - rear media
 - headphones.....132
 - home screen.....135
 - video media player controls.....124
- Message centre display units.....43
- Methanol.....185
- Minor paintwork repairs.....199
- Mirrors
 - blind spot monitor.....93–95
 - dip when reversing.....57
 - exterior mirrors.....56
- Misfuel device.....188
- Modes
 - driving.....90
 - winter.....90
- Mpg.....190
- N**
 - Navigation
 - address entry.....165
 - alerts.....170
 - approach mode.....172
 - connected navigation.....171
 - door to door routing.....173
 - edit route.....169
 - from the rear seats.....168
 - fuel finder.....171
 - fuel prices service.....172
 - instrument panel view.....171
 - main menu
 - search.....166
 - map
 - auto zoom.....169
 - split screen.....168
 - updates.....170
 - menu.....165
 - my commute.....171
 - online routing.....173
 - online service.....172
 - operating.....162
 - overview.....162
 - profiles.....173
 - real time traffic flow.....172
 - route planning web portal.....173
 - safety cameras.....173
 - satellite view.....173
 - search.....166
 - settings.....169
 - share.....173
 - view options.....169
 - your favourites.....170
- O**
 - Obstructing the airbag.....36
 - Occupant safety
 - child seat tether straps.....33
 - cleaning seat belts.....202
 - recommended child seats.....31

Index

- seat belt checks.....26
- seat belt pre-tensioners.....25
- seat belt reminder warning.....26
- seat belt safety.....25
- seat belts warning lamp.....45
- using seat belts.....23
- Octane rating.....184
 - petrol.....184
- Oil
 - engine oil specification.....207
 - filler locations.....203
 - specification.....245
 - top up.....207
 - used engine oil.....195
- One-touch operation (windows).....61
- Opening the bonnet.....195
- Opening the luggage compartment.....65
- Oversteer.....76
- Overview
 - InControl mobile technology.....179
- Owner maintenance.....194
- P**
- Paddle shift.....75
- Paintwork
 - cleaning.....199
 - repair.....199
- Pairing
 - via the phone.....157
- Park assist
 - cleaning sensors and cameras.....199
 - limitations.....149
 - options.....147
 - selecting.....148
 - troubleshooting.....149
 - using.....148
- Parking aids
 - adjusting the volume.....146
 - cleaning sensors and cameras.....199
 - park assist.....147
 - limitations.....149
 - selecting.....148
 - troubleshooting.....149
 - using.....148
 - reverse traffic detection.....150
 - sensors.....151
 - single rear camera.....152
 - system fault.....146
 - using.....145
- Parking brake.....80
 - warning lamp.....45
- Particle filter.....194
- Parts.....193
- Passenger compartment fuse box.....220
- Passive alarm arming.....11
- Passive entry.....6
- Pedestrian protection system.....241
 - after deployment.....241
- Perimeter alarm.....11
- Petrol
 - fuel types.....184
- Petrol consumption.....190
- Petrol filler flap.....188
- Phone
 - Bluetooth compatibility.....157
 - call volume.....159
 - compatibility list.....157
 - contacts.....159
 - icons.....158
 - InControl.....180
 - managing two calls.....158
 - merge calls.....158
 - microphone volume.....159
 - overview.....156
 - pairing via the phone.....157
 - steering wheel controls.....159
- Phone safety.....157
- Polishing the bodywork.....200
- Portable media
 - Bluetooth wireless technology.....161
 - changing device.....123
 - connecting a media device.....119
 - connecting multiple devices.....122
 - connections.....118
 - controls.....120
 - importing/ripping media.....123
 - pairing.....122
 - playing.....121

- Power sockets.....64
- Power steering
 fluid
 specification.....210
 fluid level.....209
- Pressure checking (tyres)
 checking after a repair.....235
- Pressures
 tyres.....227
- Progress control
 overview.....97
 settings.....98
 using the system.....97
- Progress control warning lamp.....46
- Puncture repair kit.....233
 instructions for use.....233
 repair procedure.....234
 safety.....233
- Q**
- Queue assist (ACC).....85
- R**
- Radio
 automatic station retune.....115
 DAB
 settings.....117
 DAB controls.....116
- Radio frequency regulations.....251
- Rain sensor.....55
- Rear fog lamps warning lamp.....46
- Rear lamp
 bulb changing.....197
 removal.....197
- Rear media
 deploying the rear seat screens.....133
 headphones.....132
 home screen.....135
 remote control
 batteries.....134
 remote control use.....133
 screens overview.....135
 touch screen controls.....108
- Rear screen cleaning.....200
- Rear seat entertainment
 deploying the screens.....133
 headphones.....132
 home screen.....135
 remote control.....133
 remote control batteries.....134
- Rear seats
 executive class.....16
 massage seats.....17
 executive class seats.....14
 folding table.....17
 passenger seat away.....14
 position memory.....16
 safety.....17
- Rear seat screens
 home menu.....135
 navigation.....168
 overview.....135
 rear climate.....139
- Rear window blind.....60
- Recalling seat memory position.....15
- Recommended tyre pressures.....232
- Recording
 event data.....241
 service data.....241
- Recovery
 towing eyes.....240
 transporting.....240
- Refuelling
 diesel.....185
 diesel fuel sulphur content.....185
 ethanol.....184
 fuel filler flap.....188
 methanol.....185
 MTBE.....185
 octane rating.....184
 petrol.....184
 running out of fuel.....187
 safety precautions.....184
- Reminder (seat belt).....26
- Remote control
 batteries.....134
 care.....7

driving position memory.....	14
rear media.....	133
single locking.....	9
smart key battery.....	7
system transmitters.....	250
Removing a rear head restraint.....	21
Removing stains.....	201
Repairing paintwork damage.....	199
Replacement tyres.....	229
Resetting the windows.....	197
Restarting the engine while moving.....	71
Restricted seat travel.....	15
Resume speed and follow mode (ACC).....	85
Reverse parking aids	
adjusting the volume.....	146
parking aid system fault.....	146
reverse traffic detection.....	150
sensors.....	151
using.....	145
Road sign recognition.....	92
Rolling re-start.....	71
Rotary gear selector.....	75
Running-in.....	193
Running out of fuel.....	187

S

Safety

child safety locks.....	28
cleaning seat belts.....	202
fuel and refuelling.....	184
seat belt checks.....	26
seat belt pre-tensioners.....	25
seat belt reminder warning.....	26
seat belts.....	25
seat belts warning lamp.....	45
seats for larger children.....	32
sitting correctly.....	15
tyre care.....	227
tyre pressures.....	227
used engine oil.....	195
using seat belts.....	23
using the phone.....	157
warning triangle.....	198

Safety in the garage	
battery precautions.....	195
electrical components.....	195
engine fans.....	195
exhaust gases.....	195
hot components.....	195
jacking.....	195
Satellite navigation	
address entry.....	165
alerts.....	170
approach mode.....	172
connected navigation.....	171
door to door routing.....	173
edit route.....	169
fuel finder.....	171
fuel prices service.....	172
instrument panel view.....	171
map	
auto zoom.....	169
split screen.....	168
updates.....	170
menu.....	165
my commute.....	171
online routing.....	173
online service.....	172
operating.....	162
overview.....	162
profiles.....	173
real time traffic flow.....	172
route planning web portal.....	173
safety cameras.....	173
satellite view.....	173
search.....	166
settings.....	169
share.....	173
view options.....	169
your favourites.....	170
Screen wash	
check.....	210
specification.....	245
topping up.....	211
Seat belts.....	23, 202
adjusting.....	23
checks.....	26

pre-tensioners.....	25	closing mislock.....	10
reminder warning.....	26	deactivating the alarm.....	11
safety.....	25	lock confirmation.....	9
warning lamp.....	45	locking with the emergency key.....	12
Seats		perimeter alarm.....	11
child restraint check list.....	32	single locking.....	9
child seat positioning.....	29	Security sensors	
child seats.....	28	fault.....	12
child seat tether straps.....	33	Sensors	
cleaning seat belts.....	202	blockage.....	95
climate seats.....	142	Sequential shift.....	74
comfort and adjustment.....	141	Service interval indicator.....	43
electric front.....	13	Servicing	
electric front head restraints.....	19	airbags.....	38
executive class rear.....	16	data recording.....	241
massage seats.....	17	Set speed limit.....	81
executive rear seats.....	14	Settings	
front head restraints.....	19	audio.....	109
heated.....	141	general.....	106
ISOFIX installation.....	32	guidance	
passenger seat away.....	14	navigation system.....	169
position memory.....	14	system.....	106
rear folding table.....	17	Settings menu.....	41
rear head restraints.....	20	display units.....	43
rear seat position memory.....	16	Side airbags.....	37
rear seat safety.....	17	Side lamps warning lamp.....	47
rear seat screens overview.....	135	Side window blind	
recalling a memory position.....	15	reset.....	198
recommended child seats.....	31	Side window blinds.....	61
remote seats.....	144	Sign recognition.....	92
settings.....	144	Silencing the alarm.....	11
removing a rear head restraint.....	21	Sim card	
restricted seat travel.....	15	connecting.....	178
seat belts warning lamp.....	45	Sitting correctly.....	15
seat comfort and adjustment.....	15	Smart key	
seat massage.....	142	approach lamps.....	50
sitting correctly.....	15	battery changing.....	7
Securing luggage.....	67	care.....	7
Security	10	driving position memory.....	14
alarm.....	193	single locking.....	9
tilt sensor.....	11	transmitters.....	250
automatic perimeter alarm.....	11	Smartphone	
automatic relocking and arming.....	11	InControl.....	180
battery backed sounder.....	11	InControl app.....	179, 182

Index

InControl protect link.....	179
Snow chains.....	230
SOS emergency call	
InControl protect link.....	179
Specifications	
capacities.....	249
dimensions.....	247
engine.....	244
ethanol.....	184
fluids.....	245
fuel tank capacity.....	189
label locations.....	243
lubricants.....	245
methanol.....	185
MTBE.....	185
weight.....	246
Speed-dependent wipers.....	55
Speed limiting.....	81
Speedometer.....	40
Split screen map.....	168
SRS.....	35
airbag warning lamp.....	46
Stability control	
active differential.....	76
DSC.....	76
switching between DSC and tracDSC.....	76
switching on.....	76
switching off.....	76
tracDSC.....	76
Starting after a collision.....	241
Starting the engine.....	70
failure to start.....	71
keyless start backup.....	71
Status icons	
touch screen.....	101
Steering column	
lock.....	7
vehicle recovery.....	7
Steering wheel	
adjusting.....	22
AUTO position.....	22
audio controls.....	108
heated.....	22
Steering wheel controls	
speed limiter.....	81
Stolen vehicle	
InControl secure.....	181
Stop/start	
activating.....	72
deactivating.....	72–73
Storage compartments.....	63
cup holders.....	63
front cubby box.....	63
rear armrest.....	63
Storage compartments areas	
glove box.....	63
Sun blind.....	60
Sun blinds	
side windows.....	61
Sunroof	
anti-trap protection.....	62
reset.....	197
Supplementary restraint system (SRS)	
airbag deployment.....	38
airbag locations.....	35
airbags maintenance.....	193
airbag warning lamp.....	38, 46
curtain airbags.....	37
front airbags.....	37
side airbags.....	37
Surround cameras.....	153
touch screen menu.....	153
Suspension	
adaptive dynamics.....	78
Switch cleaning.....	200
Switching off the engine.....	70
Switching on the ignition.....	70
T	
Table.....	17
Tachometer.....	40
Technical specifications	
brake fluid.....	245
capacities.....	249
dimensions.....	247
engine.....	244
engine coolant.....	245

engine oil.....	245	portable media playing.....	121
radio frequency regulations.....	251	rear media control.....	108
washer fluid.....	245	rear seat screen	
weights.....	246	seat comfort.....	17
Telephone		remote seats.....	144
Bluetooth compatibility.....	157	seat comfort and adjustment.....	15
Bluetooth wireless technology.....	161	seat settings.....	144
call volume.....	159	status icons.....	101
contacts.....	159	surround cameras.....	153
icons.....	158	system settings.....	106
managing two calls.....	158	touch screen care.....	101
merge calls.....	158	TV controls.....	126
microphone volume.....	159	valet mode.....	104
overview.....	156	deselecting.....	104
pairing		video player controls.....	124
via the phone.....	157	Tow eye (front).....	240
steering wheel controls.....	159	Towing	
Telephone safety.....	157	eyes.....	240
Television		tracDSC	
controls.....	126	stability control.....	76
Tilt sensor.....	11	Tracking your vehicle	
Touch screen.....	201	InControl secure.....	181
changing portable media device.....	123	Traction control	
connecting multiple portable media		switching between DSC and tracDSC.....	76
devices.....	122	switching off.....	76
connectivity settings.....	177	switching on.....	76
DAB radio controls.....	116	tracDSC.....	76
dual view.....	130	Traffic sign recognition.....	92
dual view controls.....	130	Transmission	
editing screens.....	102	automatic.....	74
editing shortcuts.....	102	gear shift warning lamp.....	47
editing widgets.....	102	identification number.....	243
extra features.....	104	limp home mode.....	75
general settings.....	106	Transmitters	
heated seats.....	141	smart key.....	250
home menu.....	100	Transporting the vehicle.....	240
inhibited display.....	125	Trip computer.....	42
massage seats.....	142	average speed.....	42
my home screen.....	102	fuel consumption.....	42
operating.....	101	fuel range.....	42
portable media		reset.....	42
controls.....	120	trip distance.....	42
portable media connections.....	118	TV	
portable media pairing.....	122	controls.....	126

Index

dual view.....	130
dual view controls.....	130
Tyre pressure checking after a repair.....	235
Tyre pressure monitoring system (TPMS).....	231
tyre care.....	227
valves.....	229
warning lamp.....	47
Tyre repair kit	
checking pressures.....	235
repair procedure.....	234
safety information.....	233
using.....	233
Tyres	
age degradation.....	229
changing.....	232
flat spots.....	229
important information.....	239
Indian regulations.....	230
pressure check.....	231
pressures.....	227
recommended tyre pressure look-up.....	232
repair kit.....	233
repair kit use.....	233
repair procedure.....	234
replacements.....	229
snow chains.....	230
speed ratings.....	227
temporary use spare.....	232
TPMS.....	231
warning lamp.....	47
tyre care.....	227
tyre repair safety.....	233
tyre wall markings.....	226
use of spare tyre.....	239
valves.....	229
wall markings.....	226
winter.....	229

U

Under bonnet covers.....	196
Understeer.....	76
Unlocking.....	9
all doors.....	4
driver's door.....	4

entry and exit mode.....	22
global opening.....	4, 6
keyless entry.....	6
luggage compartment emergency	
release.....	67
mode.....	4
multi point entry.....	4
passive entry.....	6
single point entry.....	4
USB devices	
connecting multiple devices.....	122
Used engine oil.....	195
Using adaptive cruise control.....	83
Using cruise control.....	82
Using the spare tyre	
important information.....	239

V

Valet mode.....	104
deselecting.....	104
Vehicle alarm.....	193
Vehicle battery	
battery monitoring system.....	213
connecting jump leads.....	213
replacing.....	215
warning symbols.....	212
Vehicle battery care.....	212
Vehicle build date.....	243
Vehicle cleaning	
airbag covers.....	202
alloy wheels.....	199
automatic car wash.....	199
carpets and mats.....	202
engine compartment.....	199
interior.....	200–201
rear screen.....	200
sunroof.....	200
washer jets.....	196
Vehicle data recording.....	241
Vehicle identification	
transmission number.....	243
Vehicle location	
InControl secure.....	181

- Vehicle recovery
 - attaching the front tow eye.....240
 - steering column lock.....7
 - towing eyes.....240
 - transporting the vehicle.....240
 - Video media player
 - controls.....124
 - dual view.....130
 - controls.....130
 - full screen view.....125
 - inhibited display.....125
 - VIN number.....243
 - Voice control.....175
 - settings
 - command list.....176
 - operating guide.....176
 - preferences.....176
 - voicetags.....176
 - voice training.....176
 - tutorial.....175
 - voicetags.....176
- ## W
- Warning lamps.....44
 - ABS.....45
 - ACC follow mode.....46
 - adaptive front lighting system (AFS).....45
 - airbags.....38, 46
 - audible warnings and indicators.....48
 - automatic speed limiter.....46
 - battery charge.....45
 - brake.....44–45
 - critical warning message.....44
 - cruise control.....47
 - diesel glow plugs.....46
 - DSC active.....46
 - engine/transmission.....45
 - engine temperature.....44
 - external temperature.....46
 - forward alert.....47
 - gear shift warning lamp.....47
 - headlamp high beam.....47
 - high beam assist.....47
 - indicators.....47
 - intelligent stop/start (amber).....46
 - intelligent stop/start (green).....47
 - lamp test.....44
 - low fuel.....46
 - low oil pressure.....44
 - parking brake.....45
 - progress control system.....46
 - rear fog lamps.....46
 - seat belt.....45
 - side lights.....47
 - tyre pressure monitoring system (TPMS).....47
 - Warning messages.....41
 - Warning triangle.....198
 - Washer jets.....196
 - Washer reservoir
 - capacity.....249
 - Washers.....54
 - fluid specification.....211
 - fluid top up.....211
 - headlamps.....55
 - Washing
 - automatic car wash.....199
 - exterior paintwork.....199
 - removing grease.....200
 - removing stains.....201
 - removing tar.....200
 - soft top.....200
 - Water in fuel.....187
 - Weights
 - gross vehicle weights.....246
 - roof load.....246
 - roof rack weight.....246
 - vehicle weights.....246
 - Wheel changing
 - important information.....239
 - locking wheel nuts.....239
 - recommended process.....238
 - safety warnings.....237
 - tilt sensor.....238
 - use of spare tyre.....239
 - Wheels and tyres
 - age degradation.....229
 - changing a tyre.....232

Index

checking the pressures after a repair.....	235
flat spots.....	229
Indian regulations.....	230
pressures.....	227
puncture repair.....	233
puncture repair safety.....	233
repair kit.....	233
repair kit use.....	233
repair procedure.....	234
replacements.....	229
snow chains.....	230
temporary use spare.....	232
TPMS.....	231
TPMS warning lamp.....	47
tyre care.....	227
tyre speed ratings.....	227
tyre wall markings.....	226
valves.....	229
winter tyres.....	229
Wheel spin.....	76
Wi-Fi connection icons.....	178
Windows	
anti-trap protection.....	62
one-touch operation.....	61
operation.....	60
reset.....	197
side window blinds.....	61
sunroof reset.....	197
Winter park position.....	197
Winter tyres.....	229
Wipers.....	54
Wipers and washers.....	54
fluid level.....	210
rain sensor.....	55
speed-dependent mode.....	55
Wireless technology	
Bluetooth.....	161
X	
Xenon headlamps.....	196

