

Touch screen - Settings

GENERAL SETTINGS

Touch the Settings icon from any screen, followed by **All Settings** and then **General**.

The **General** settings menu is divided into categories:

- **Time and Date**

***Note:** Setting a year too far in the future could stop certain online apps from working, as the certificate will appear to be invalid.*

- **Display**

- **Screensaver**

- **Master PIN**

***Note:** The default Master PIN is **1926**. This should be changed to your own PIN as soon as possible.*

- **Legal information**

- **Data Collection** (only when set).

Touch to display the list of settings for the required system.

SYSTEM SETTINGS

Touch the Settings icon from any screen, followed by **All Settings** and then **Features**.

The **Features** settings menu is divided into categories.

- **Home**

- **Navigation**

- **Media**

- **Phone**

- **Climate**

- **Rear Media**

- **Seats**

- **Connectivity**

- **Cameras**

- **InControl Apps**

- **Live**

- **Voice**

- **Bluetooth.**

Touch to display the list of settings for the required system.

***Note:** The list will vary, depending on the specification of the vehicle.*