

A

- About this handbook.....2
- Accessories.....183
- Adaptive cruise control.....105
 - ACC gap change.....107
 - automatic switch-off.....108
 - driving hints.....108
 - follow mode.....106
 - follow mode off.....107
 - forward alert.....110
 - intelligent emergency braking.....111
 - malfunction.....110
 - queue assist.....107
 - radar detection beam issues.....109
 - resume follow mode.....108
 - resume set speed.....108
 - set speed and follow mode override.....107
- Adaptive dynamics.....91
- Adaptive front lighting system.....59
 - warning lamp.....53
- Adaptive headlamps.....59
- AEB.....93
- Age degradation (tires).....223
- Air bags
 - curtain.....43
 - curtain air bags.....43
 - deployment.....42, 44
 - disability modifications.....46
 - front.....43
 - locations.....41
 - maintenance.....182
 - obstructions.....42
 - occupant sensing.....45
 - service information.....46
 - side air bags.....43
 - warning lamp.....44, 53
- Air conditioning
 - automatic recirculation.....137
 - fluid top up.....181
 - front.....135
 - rear.....139
- Air quality sensor.....137
- Alarm.....182
 - automatic relocking and arming.....15
 - battery back-up sounder.....16
 - deactivating.....17
 - passive arming.....15
 - perimeter.....15
- All surface progress control.....117–118
- All wheel drive (AWD).....90
- AM/FM radio controls.....126
- Anchor points (luggage).....80
- Anti-lock braking system
 - emergency stop signal.....95
- Anti-lock braking system (ABS) warning lamp.....54
- Anti-theft system.....182
- Anti-trap protection
 - sunroof.....76
 - windows.....75
- Arduous driving conditions.....182
- Assistance
 - InControl link.....172
- Audio
 - AM/FM radio controls.....126
 - connecting a media device.....130
 - connecting multiple devices.....133
 - licensing.....133
 - media controls.....123
 - pairing and connecting a device.....133
 - playing a portable device.....133
 - portable media connections.....129
 - portable media controls.....132
 - satellite radio controls.....128
 - satellite radio reception.....129
 - satellite subscription.....129
 - settings.....124
- Audio settings.....124
- Auto lamps
 - wiper detection.....59
- Automatic locking.....13, 15
- Automatic recirculation.....137
- Automatic speed limiter
 - warning lamp.....54
- Automatic speed limiter (ASL).....100
- Automatic switch off of ACC.....108
- Automatic transmission.....86

gear shift warning lamp.....	55
shift paddles.....	88
temporary manual selection.....	88
Autonomous emergency braking (AEB).....	93
Auxiliary device connection.....	130, 133
Auxiliary power sockets.....	79
Avoiding tire flat spots.....	223

B

Battery

boost starting.....	209
care.....	206
charging.....	209
connecting jump leads.....	207
disconnection.....	210
effects of disconnection.....	210
maintenance.....	206
monitoring system.....	210
removing.....	209
replacing.....	209
using a starting aid.....	209
warning lamp.....	52
warning symbols.....	206
Battery back-up sounder.....	16
Blinds.....	76
rear window.....	74

Blind spot monitor

closing vehicle sensing.....	68
displayed messages.....	69
frequency information.....	70
notification of overtaking vehicle.....	67
sensor blockage.....	69

Bluetooth

changing the connected phone or device.....	157
deleting the connected phone.....	158
general information.....	156
pairing and connecting a device.....	133
pairing a wireless technology device.....	156
phone compatibility.....	156
telephone	
overview.....	152
safety.....	153
Booster seats for larger children.....	38

Boost starting.....	209
---------------------	-----

Brakes

ABS warning lamp.....	54
autonomous braking.....	93
control with ABS.....	92
electronic brake force distribution.....	92
emergency assist.....	111
emergency brake assist.....	92
emergency stop signal.....	95
fluid check.....	203
fluid specification.....	204
fluid top up.....	204
handbrake.....	94
hill start assist.....	95
important information.....	92
parking brake warning lamp.....	53
steep slope control.....	92
warning lamp (amber).....	54
warning lamp (red).....	52

Breakdown assistance

InControl link.....	171
---------------------	-----

Bulbs

changing a bulb.....	185
rear lamp.....	192
rear lamps.....	189

C

California proposition 65.....	2
--------------------------------	---

California proposition 65 second warning.....	206
---	-----

Call volume.....	154
------------------	-----

Cameras

proximity view.....	150
rear camera.....	142, 145
reverse traffic detection.....	144
touch screen menu.....	150

Capacities.....	245
-----------------	-----

engine oil.....	245
fuel tank.....	245
washer reservoir.....	245

Car-wash.....	195
---------------	-----

Changing a bulb.....	185
----------------------	-----

Changing a fuse.....	212
----------------------	-----

Changing a wheel

recommended process.....	234
--------------------------	-----

safety warnings.....	232	Climate seats.....	137
spare wheel.....	236	Climate settings.....	136
temporary spare wheel.....	237	Clock.....	47
Changing the connected phone or device.....	157	Closing the hood.....	184
Charging the vehicle battery.....	209	Closing vehicle sensing.....	68
Chassis number.....	241	Commandshift.....	86
Child safety		Compatibility of phones.....	156
booster seats.....	38	Condensation (headlamps).....	59
check list.....	37	Configurable dynamics.....	116
child seats.....	34	Connecting a media device.....	130
larger children on booster seats.....	38	Connecting a phone or device.....	156
LATCH installation.....	38	Connecting jump leads.....	207
lock and window inhibitor.....	34	Connecting multiple portable media devices.....	133
positioning.....	35	Controls	
tether straps.....	39	touch screen.....	120
Cleaning		Controls cleaning.....	196
air bag covers.....	198	Convenience mode.....	10
alloy wheels.....	196	Coolant	
automatic car wash.....	195	checking the level.....	202
engine compartment.....	195	specification.....	203
exterior.....	195	top up.....	203
paintwork.....	195	Courtesy delay.....	58
glass.....	196	Covers	
interior.....	196–197	engine.....	185
leather.....	197	Critical warning messages.....	52
park assist sensors.....	195	Cruise control.....	104
parking aids sensors.....	195	ACC driving hints.....	108
polishing.....	196	ACC emergency braking.....	111
rear screen.....	196	ACC follow mode.....	106
removing grease.....	196	ACC gap change.....	107
removing stains.....	197	ACC radar detection beam issues.....	109
removing tar.....	196	ACC set speed and follow mode override.....	107
sensors and cameras.....	195	adaptive cruise control.....	105
sunroof.....	196	adaptive cruise control malfunction.....	110
using a car-wash.....	195	follow mode.....	106
washer jets.....	199	forward alert in ACC.....	110
wipers.....	198	resume ACC follow mode.....	108
Cleaning the wiper blades.....	198	resume ACC set speed.....	108
Climate control		using ACC.....	105
automatic recirculation.....	137	warning lamp.....	55
front.....	135	Curtain air bags.....	43
heated and cooled seats.....	137		
heated seats.....	137		
rear.....	139		

- ## D
- Data recording.....240
 - Daytime running lamps.....57
 - Declaration of conformity.....154
 - Deleting the connected phone or device.....158
 - Deselecting valet mode.....122
 - Detection beam issues.....109
 - Device pairing and connecting.....156
 - Differential control.....90
 - Dimensions.....247
 - Direction indicators.....57
 - Disability modifications
 - air bags.....46
 - Displays.....198
 - Door mirrors.....65
 - blind spot monitor.....67
 - closing vehicle sensing.....68
 - sensors.....69
 - Door transceiver
 - assistance.....73
 - erase all programming.....72
 - frequency regulations.....72
 - programming.....71
 - programming a single button.....72
 - programming the garage door opener.....71
 - Downloading from the internet
 - InControl connection.....174
 - Drive away locking.....13
 - Driver exit
 - deactivating intelligent stop/start.....84
 - Driver fatigue monitoring.....98
 - Driving
 - ACC automatic switch-off.....108
 - ACC driving hints.....108
 - ACC emergency braking.....111
 - ACC follow mode.....106
 - ACC forward alert.....110
 - ACC gap change.....107
 - ACC malfunction.....110
 - ACC queue assist.....107
 - ACC radar detection beam issues.....109
 - ACC set speed and follow mode
override.....107
 - activating intelligent stop/start.....84
 - adaptive cruise control.....105
 - after a collision.....240
 - arduous conditions.....182
 - autonomous braking.....93
 - before starting.....240
 - blind spot monitor.....67
 - closing vehicle sensing.....68
 - blind spot monitor messages.....69
 - brake control with ABS.....92
 - brakes important information.....92
 - breaking-in.....181
 - daily checks.....182
 - deactivating intelligent stop/start.....84
 - DSC active warning lamp.....54
 - DSC configurable modes.....116
 - electronic brake force distribution.....92
 - emergency brake assist.....92
 - emergency stop signal.....95
 - forward alert.....110
 - forward alert warning lamp.....55
 - gear shift warning lamp.....55
 - hill start assist.....95
 - lane departure warning lamp (green).....56
 - lane departure warning lamp (red).....53
 - low oil pressure.....53
 - park assist limitations.....148
 - park assist troubleshooting.....149
 - progress control settings.....118
 - progress control system overview.....117
 - rain sensor.....63
 - resume ACC follow mode.....108
 - resume ACC set speed.....108
 - selecting park assist.....147
 - sitting correctly.....20
 - steep slope control with ABS.....92
 - using ACC.....105
 - using cruise control.....104
 - using the progress control system.....117
 - weekly checks.....182
 - Driving aids
 - lane departure warning.....96
 - traffic sign recognition.....98
 - Driving assist.....97

Driving behaviour.....	98	coolant level.....	202
Driving modes.....	113	fuel types.....	177
adaptive surface response (AdSR).....	114	oil level.....	200
adverse weather.....	114	specifications.....	243
dynamic program.....	113	starting	
low friction launch.....	115	keyless start backup.....	82
standard.....	113	switching off.....	81
winter.....	114	Engine/transmission warning lamp.....	54
Driving position memory		Engine compartment	
recalling a position.....	21	fluid filler locations.....	200
Drowsiness monitoring.....	98	Engine compartment cleaning.....	195
Dynamic program.....	113	Engine covers.....	185
Dynamic stability control (DSC).....	89	Engine oil	
configurable.....	116	capacity.....	245
DSC active warning lamp.....	54	Engine starting.....	81
DSC off warning lamp.....	54	failure to start.....	82
switching between DSC and tracDSC.....	89	Engine temperature warning lamp.....	53
switching off.....	90	Entering the vehicle	
switching on.....	90	entry and exit mode.....	27
E		global opening.....	9
Eco program		luggage compartment.....	11
fuel saving.....	113	passive entry.....	10
Effects of battery disconnection.....	210	tailgate operation.....	11
Electric parking brake.....	94	unlocking mode.....	9
Electric seats.....	19	Ethanol.....	178
recalling a memory position.....	21	Event data recording.....	240
Electric windows		Exiting the vehicle	
operation.....	74	arming the alarm.....	17
Electronic brake force distribution.....	92	closing mislock.....	17
Electronic data.....	240	door locks and release levers.....	16
Email		emergency locking.....	17
InControl connection.....	174	interior locks.....	16
Emergency (navigation).....	164	lock confirmation.....	15
Emergency brake assist.....	92, 111	passive arming.....	15
Emergency call		passive locking.....	16
InControl link.....	171–172	perimeter alarm.....	15
Emergency key locking.....	17	single locking.....	15
Emergency stop signal.....	95	Exterior cleaning.....	195
hazard warning lamps.....	95	Exterior lamps	
Engine		bulb changing.....	185
antifreeze level.....	202	Exterior mirrors	
breaking-in.....	181	electric.....	65
compartment opening.....	184	manual.....	65
		mirror dip when reversing.....	66

- External temperature
 - warning lamp.....55
- Extinguisher.....194
- Extra features.....122
 - low friction launch
 - all surface info (ASI).....115
- F**
- Fatigue monitoring.....98
- Fire extinguisher.....194
- Flat spots.....223
- Fluids
 - air conditioning fluid.....181
 - brake
 - check.....203
 - specification.....204
 - top up.....204
 - capacities.....245
 - coolant
 - specification.....203
 - top up.....203
 - engine oil
 - check.....200
 - filler locations.....200
 - oil
 - top up.....202
 - specifications.....244
 - washer fluid.....205
 - check.....205
 - specification.....205
- Fog lamps
 - warning lamps
 - rear.....55
- Follow
 - override.....107
- Follow mode
 - entering.....106
 - gap change.....107
 - gap changing.....107
 - off.....56
 - override.....108
 - resume.....108
 - switching off.....107
- Forward alert.....110
 - Forward alert in ACC
 - object detection.....110
 - Forward alert warning lamp.....55
- Front air bags.....43
- Front climate control.....135
 - automatic recirculation.....137
- Front parking aids.....141
 - system fault.....142
- Front towing eye.....238
- Front wipers
 - winter park position.....192
- Fuel and refueling.....180
 - ethanol.....178
 - filler flap.....180
 - fuel filler flap.....179
 - fuel types.....177
 - methanol.....179
 - MTBE (Methyl tertiary butyl ether).....179
 - octane rating.....177
 - reformulated gasoline.....179
 - running out.....179
 - safety precautions.....177
 - tank capacity.....180
- Fuel can.....179
- Fuel filler flap.....179
- Fuel gauge.....47
- Fuel saving
 - eco program.....113
- Fuel system.....185
- Fuel tank
 - capacity.....245
- Fuses
 - changing.....212
 - engine compartment fuse box.....212
 - locations.....211
 - luggage compartment fuse box.....215
 - passenger compartment fuse box.....214
- G**
- Garage door opener.....71
 - assistance.....73
 - erase all programming.....72
 - frequency regulations.....72
 - programming.....71

- programming a single button.....72
 - Garage door transceiver.....71
 - Gasoline
 - fuel types.....177
 - Gearbox
 - automatic.....86
 - gear shift warning lamp.....55
 - limp home mode.....88
 - Glass cleaning.....196
 - Global opening.....9
- ## H
- Handbook symbols.....2
 - Handbrake.....94
 - Hands free parking.....146
 - park assist limitations.....148
 - park assist troubleshooting.....149
 - selecting park assist.....147
 - Hazard warning lamps
 - emergency stop signal.....95
 - Headlamps.....57
 - adaptive.....59
 - bulb changing.....185
 - condensation.....59
 - courtesy delay.....58
 - daytime running lamps.....57
 - high beam assist.....58
 - high beam assist warning lamp.....55
 - high beam warning lamp.....56
 - leveling.....59
 - warning lamp (AFS).....53
 - washers.....64
 - xenon.....187
 - Head restraints
 - front seats.....24
 - rear seats.....25
 - Head up display.....50
 - Heated seats.....137
 - Heated steering wheel.....28
 - Heating and ventilation.....135
 - air quality sensor.....137
 - automatic recirculation.....137
 - front.....135
 - heated and cooled seats.....137
 - heated seats.....137
 - rear.....139
 - Heating and ventilation settings.....136
 - High beam assist.....58
 - Hill start assist.....95
 - Homelink.....71
 - assistance.....73
 - erase all programming.....72
 - frequency regulations.....72
 - programming.....71
 - programming a single button.....72
 - programming the garage door opener.....71
 - Hood
 - closing.....184
 - opening.....184
- ## I
- Ignition
 - rolling re-start.....81
 - switching on.....81
 - InControl
 - apps.....175
 - overview.....171
 - protect.....171
 - remote.....172
 - wi-fi connection.....174
 - Information messages.....48, 55
 - Infotainment
 - connecting a media device.....130
 - connecting multiple devices.....133
 - licensing.....133
 - media controls.....123
 - pairing and connecting a device.....133
 - playing a portable device.....133
 - portable media
 - connections.....129
 - controls.....132
 - radio controls.....126
 - satellite radio.....128
 - reception.....129
 - subscription.....129
 - settings.....124
 - touch screen
 - care.....121

extra features.....	122
operating.....	121
Instrument panel.....	47, 198
display units.....	49
fuel range.....	49
head up display.....	50
lamp test.....	52
menu.....	47
driving features.....	47
instrument display.....	47
trip computer.....	47
vehicle set-up.....	47
recommended tire pressures.....	229
service indicator.....	50
tire pressure check.....	229
trip computer.....	48
trip distance.....	49
units.....	49
warning lamps.....	52
warning messages.....	48
Intelligent emergency braking	
ACC.....	111
Intelligent speed limiter (ISL).....	101
Intelligent speed limiter warning lamp.....	55
Intelligent stop/start	
activating.....	84
deactivating.....	84
Intelligent stop/start warning lamp.....	56
Interior cleaning.....	196–197
air bag covers.....	198
Interior lamps.....	60
ambient lighting.....	61
bulb changing.....	185
intensity.....	61
stealth mode.....	61
types.....	60
Interior locking.....	16
Internet browsing	
InControl connection.....	174
ISL warning lamp.....	55

J

Jump starting	
connecting a starting aid.....	209

connecting jump leads.....	207
----------------------------	-----

K

Keyless entry.....	10
Key transmitters.....	10

L

Label locations.....	241
Lamps.....	57
auto lamps wiper detection.....	59
bulb changing.....	185
condensation.....	59
rear lamp removal.....	189
test.....	52
TPMS warning lamp.....	55
warning lamps.....	52
xenon headlamps.....	187
Lane departure warning.....	96
Lane departure warning lamp (green).....	56
Lane departure warning lamp (red).....	53
Lane drifting.....	97
LATCH Installation.....	38
Leather cleaning.....	197
Leveling	
headlamps.....	59
License	
navigation.....	165
Lighting	
ambient lighting.....	61
interior lamps intensity.....	61
interior lamps locations.....	60
stealth mode.....	61
Limp home mode.....	88
Load securing.....	80
Locking	
automatic relocking.....	15
confirmation.....	15
door locks and release levers.....	16
drive away.....	13
emergency locking.....	17
in an emergency.....	17
mislock.....	17
passive.....	16

- single.....15
 - transmitter effects on medical devices.....10
 - with the emergency key.....17
 - Low friction launch
 - touch screen extra features.....115
 - Low fuel warning lamp.....55
 - Low oil pressure warning lamp.....53
 - Lubricants specifications.....244
 - Luggage compartment
 - anchor points.....80
- ## M
- Maintenance
 - air conditioning.....181
 - arduous driving conditions.....182
 - brake fluid level.....203
 - breaking-in.....181
 - bulb changing.....185
 - rear lamp removal.....189
 - capacities.....245
 - changing a fuse.....212
 - cleaning
 - alloy wheels.....196
 - exterior.....195
 - glass.....196
 - interior.....196–197
 - leather.....197
 - rear screen.....196
 - sensors and cameras.....195
 - the engine compartment.....195
 - closing the hood.....184
 - daily checks.....182
 - engine compartment fuse box.....212
 - engine coolant level.....202
 - engine oil level.....200
 - fuel system.....185
 - fuse box (passenger compartment).....214
 - jump starting.....209
 - label locations.....241
 - lubricants and fluid specifications.....244
 - luggage compartment fuse box.....215
 - oil top up.....202
 - paintwork repair.....199
 - polishing.....196
 - removing grease and tar.....196
 - removing stains.....197
 - smart key battery.....13
 - sunroof wind deflector.....196
 - using a starting aid.....209
 - washer fluid level.....205
 - weekly checks.....182
 - Map screen
 - navigation system.....162
 - Media controls.....123
 - Message center display units.....49
 - Methanol.....179
 - Minor paintwork repairs.....199
 - Mirrors
 - blind spot monitor.....67
 - closing vehicle sensing.....68
 - sensors.....69
 - dip when reversing.....66
 - exterior mirrors.....65
 - Modes
 - adaptive surface response (AdSR).....114
 - driving.....113
 - low friction launch.....115
 - standard.....113
 - winter.....114
 - Monitoring driver behaviour.....98
- ## N
- Navigation
 - emergency contacts.....164
 - license.....165
 - map screen.....162
 - menu.....161
 - operating.....159
 - overview.....159
 - points of interest (POI).....164
 - SD card.....159
 - set a selected destination.....164
 - settings.....162
 - guidance.....163
 - soft key icons.....165
 - terms and conditions.....165
 - voice commands.....169
 - where to?.....163

- O**
- Obstructing an air bag.....42
 - Occupant safety
 - child seat tether straps.....39
 - seat belt checks.....31
 - seat belt locking.....32
 - seat belt pre-tensioners.....30
 - seat belt reminder warning.....32
 - seat belt safety.....31
 - seat belts warning lamp.....53
 - using seat belts.....29
 - Octane rating.....177
 - Oil
 - engine oil specification.....202
 - filler locations.....200
 - specification.....244
 - top up.....202
 - used engine oil.....184
 - Opening the hood.....184
 - Oversteer.....89
 - Overview
 - InControl mobile technology.....171
 - Owner maintenance.....181
- P**
- Paddle shift.....88
 - Paintwork
 - cleaning.....195
 - repair.....199
 - Pairing a phone or device.....156
 - Park assist.....147
 - cleaning sensors and cameras.....195
 - hands free parking.....146
 - limitations of use.....148
 - selecting.....147
 - troubleshooting.....149
 - Park assist options.....147
 - Parking aids
 - cleaning sensors and cameras.....195
 - operating.....141
 - rear camera.....142, 145
 - reverse traffic detection.....144
 - system fault.....142
 - Parking brake.....94
 - warning lamp.....53
 - Parts.....183
 - Passenger compartment fuse box.....214
 - Passive alarm arming.....15
 - Passive entry.....10
 - Passive locking.....16
 - Perimeter alarm.....15
 - Phone
 - call volume.....154
 - deleting the connected phone or device.....158
 - overview.....152
 - safety.....153
 - steering wheel controls.....153
 - Phone compatibility.....156
 - Playing a portable device.....133
 - Points of interest (POI).....164
 - Polishing the bodywork.....196
 - Portable media
 - Bluetooth wireless technology.....156
 - connections.....129
 - controls.....132
 - Portable media pairing.....156
 - Power sockets.....79
 - Progress control
 - overview.....117
 - settings.....118
 - using the system.....117
 - Progress control warning lamp.....55
 - Proposition 65 second warning.....206
- Q**
- Queue assist (ACC).....107
- R**
- Radio
 - satellite radio controls.....128
 - satellite radio reception.....129
 - Radio frequency ID (RFID).....76
 - Radio frequency regulations.....250
 - Radio reception
 - satellite radio.....129
 - Rain sensor.....63

Rear camera		Reporting safety defects.....	6
parking aids.....	142	Resetting the windows.....	193
reverse traffic detection.....	144	Restarting the engine while moving.....	81
sensors.....	145	Resume speed and follow mode (ACC).....	108
Rear climate control.....	139	Reverse parking aids.....	141
Rear fog lamps warning lamp.....	55	rear camera.....	145
Rear lamp		reverse traffic detection.....	144
bulb changing.....	189	system fault.....	142
removal.....	189	Road sign recognition.....	98
Rear screen cleaning.....	196	Rolling re-start.....	81
Rear seats		Rolling roads.....	183
folding and raising.....	22	Running-in.....	181
safety.....	22	Running out of fuel.....	179
Rear towing eye.....	239		
Rear window blind.....	74	S	
Recalling seat memory position.....	21	Safety	
Recommended tire pressures.....	229	child safety locks.....	34
Recording		fuel and refueling.....	177
event data.....	240	seat belt checks.....	31
service data.....	240	seat belt locking mechanism.....	32
Recovery		seat belt pre-tensioners.....	30
transporting.....	238	seat belt reminder warning.....	32
Reformulated gasoline.....	179	seat belts.....	31
Refueling		seat belts warning lamp.....	53
ethanol.....	178	seats for larger children.....	38
fuel filler flap.....	179	sitting correctly.....	20
fuels.....	177	tire care.....	219
methanol.....	179	tire degradation.....	223
MTBE.....	179	tire load limit.....	227
octane rating.....	177	tire pressures.....	220
reformulated gasoline.....	179	tire temperature.....	226
running out of fuel.....	179	tire tread wear.....	225
safety precautions.....	177	traction devices.....	224
Reminder (seat belt).....	32	used engine oil.....	184
Remote control		using seat belts.....	29
care.....	14	using the telephone.....	153
single locking.....	15	winter tires.....	223
smart key battery.....	13	Safety defect reporting.....	6
system transmitters.....	249	Safety in the garage	
Removing stains.....	197	battery precautions.....	183
Removing the spare wheel.....	236	electrical components.....	183
Removing the vehicle battery.....	209	engine fans.....	183
Repairing paintwork damage.....	199	exhaust gases.....	183
Replacement tires.....	222	hot components.....	183

- jacking.....183
- Satellite navigation
 - emergency contacts.....164
 - map screen.....162
 - menu.....161
 - operating.....159
 - overview.....159
 - points of interest (POI).....164
 - SD card.....159
 - set a selected destination.....164
 - settings.....162
 - guidance.....163
 - soft key icons.....165
 - voice commands.....169
 - where to?.....163
- Satellite radio
 - controls.....128
 - reception.....129
 - subscription.....129
- Screen wash
 - check.....205
 - specification.....244
 - topping up.....205
- SD card
 - navigation system.....159
- Seat belts.....29
 - adjusting.....29
 - checks.....31
 - locking mechanism.....32
 - pre-tensioners.....30
 - reminder warning.....32
 - safety.....31
 - warning lamp.....53
- Seats
 - child restraint check list.....37
 - child seat positioning.....35
 - child seats.....34
 - child seat tether straps.....39
 - climate.....137
 - electric front.....19
 - front head restraints.....24
 - heated.....137
 - LATCH installation.....38
 - rear head restraints.....25
 - rear seat folding and raising.....22
 - rear seat safety.....22
 - recalling a memory position.....21
 - seat belts warning lamp.....53
 - sitting correctly.....20
- Securing luggage.....80
- Security
 - alarm.....182
 - automatic perimeter alarm.....15
 - automatic relocking and arming.....15
 - battery back-up sounder.....16
 - closing mislock.....17
 - deactivating the alarm.....17
 - lock confirmation.....15
 - locking with the emergency key.....17
 - perimeter alarm.....15
 - single locking.....15
- Selecting valet mode.....122
- Sensors
 - blockage.....69
- Sequential shift.....86
- Service interval indicator.....50
- Servicing
 - air bags.....46
 - data recording.....240
- Setting a destination
 - navigation system.....164
- Settings
 - guidance
 - navigation system.....163
 - navigation system.....162
- Settings menu.....47
 - display units.....49
- Setting the heating and ventilation.....136
- Setting the touch screen.....121
- Side lamps warning lamp.....56
- Sidewall information (tires).....218
- Side window blinds.....76
- Sign recognition.....98
- Silencing the alarm.....17
- Sitting correctly.....20
- Smart key
 - battery changing.....13
 - care.....14

single locking.....	15
transmitters.....	249
Smartphone	
InControl app.....	171–172, 175
InControl protect link.....	171
InControl remote link.....	172
Snow chains.....	224
Soft keys	
navigation system.....	165
Solar attenuating glass.....	76
SOS emergency call	
InControl protect link.....	171
InControl remote link.....	172
Spare wheel.....	236
using wheel chocks.....	237
Specifications	
capacities.....	245
dimensions.....	247
engine.....	243
ethanol.....	178
fluids.....	244
fuel tank capacity.....	180
label locations.....	241
lubricants.....	244
methanol.....	179
MTBE.....	179
weight.....	246
Speed-dependent wipers.....	64
Speed limiter	
automatic speed limiter.....	100
intelligent speed limiter.....	100
overview.....	100
Speedometer.....	47
Speed ratings for tires.....	219
SRS	
air bag warning lamp.....	53
Stability control	
all wheel drive (AWD).....	90
awd.....	90
DSC.....	89
configurable.....	116
switching between DSC and tracDSC....	89
switching on.....	90
switching off.....	90
tracDSC.....	89
Starting after a collision.....	240
Starting the engine.....	81
failure to start.....	82
keyless start backup.....	82
Stealth mode.....	61
Steering column	
lock.....	10
vehicle recovery.....	10
Steering correction.....	97
Steering wheel	
adjusting.....	27
AUTO position.....	27
heated.....	28
Steering wheel controls	
telephone.....	153
Stop/start	
activating.....	84
deactivating.....	84
Storage compartments.....	78
cup holders.....	78
front cubby box.....	78
rear armrest.....	78
Storage compartments areas	
glove box.....	78
Subscription	
satellite radio.....	129
Sun blind.....	74
Sun blinds	
side windows.....	76
Sunroof	
anti-trap protection.....	76
reset.....	193
Supplementary restraint system (SRS)	
air bag deployment.....	44
air bag locations.....	41
air bags maintenance.....	182
air bag warning lamp.....	44, 53
curtain air bags.....	43
front air bags.....	43
obstructing an air bag.....	42
occupant sensing.....	45
side air bags.....	43
Surround cameras.....	150

Index

- touch screen menu.....150
- Suspension
 - adaptive dynamics.....91
- Switch cleaning.....196
- Switching off the engine.....81
- Switching on the ignition.....81
- T**
- Tachometer.....47
- Technical specifications
 - brake fluid.....244
 - capacities.....245
 - dimensions.....247
 - engine.....243
 - engine coolant.....244
 - engine oil.....244
 - radio frequency regulations.....250
 - washer fluid.....244
 - weights.....246
- Telephone.....152
 - Bluetooth wireless technology.....156
 - call volume.....154
 - deleting the connected phone or device..158
 - overview.....152
 - safety.....153
 - steering wheel controls.....153
- Telephone compatibility.....156
- Telephone connecting.....156
- Telephone pairing.....156
- Terms and conditions
 - navigation.....165
- Tinted front screen.....76
- Tire grading system.....225
- Tire pressure monitoring system (TPMS)..228
 - type approval information.....230
 - valves.....222
 - warning lamp.....55
- Tire pressures.....229
- Tires
 - age degradation.....223
 - care.....219
 - changing.....230
 - degradation.....223
 - flat spots.....223
 - glossary of terms.....226
 - grading system.....225
 - important information.....237
 - information label.....220
 - load limit.....227
 - pressure check.....229
 - pressures.....220
 - recommended tire pressure look-up.....229
 - replacements.....222
 - replacing.....222
 - speed ratings.....219
 - temperature resistance.....226
 - temporary use spare.....230
 - tire pressure monitoring system (TPMS).....228
 - warning lamp.....55
 - traction devices.....224
 - tread wear.....225
 - uniform tire quality grading.....225
 - use of spare tire.....237
 - valves.....222
 - vehicle loading.....229
 - winter tires.....223
- Toll road payment.....76
- Touch screen.....198
 - automatic recirculation.....137
 - button feedback.....121
 - clock.....121
 - eco data.....113
 - extra features.....122
 - front climate control.....135
 - fuel economy facts.....113
 - general settings.....121
 - heated and cooled seats.....137
 - heated seats.....137
 - language selection.....121
 - operating.....121
 - shortcuts.....121
 - surround cameras.....150
 - system settings.....121
 - touch screen care.....121
 - valet mode.....122
 - volume presets.....121

Towing eyes	
front.....	238
rear.....	239
tracDSC	
stability control.....	89
Traction control	
switching between DSC and tracDSC.....	89
switching off.....	90
switching on.....	90
tracDSC.....	89
Traction devices.....	224
Traffic sign recognition.....	98
Transmission	
automatic.....	86
gear shift warning lamp.....	55
limp home mode.....	88
Transmitters	
smart key.....	249
Transporting the vehicle.....	238
Tread wear.....	225
Trip computer.....	48
average speed.....	49
fuel consumption.....	49
fuel range.....	49
reset.....	49
trip distance.....	49
Turning ACC follow mode off.....	56
Turn signals	
warning lamp.....	56
Type approvals.....	154
U	
Under hood covers.....	185
Understeer.....	89
Uniform tire quality grading.....	225
Unlocking.....	16
all doors.....	7
driver's door.....	7
entry and exit mode.....	27
global opening.....	7, 9
luggage compartment.....	11
mode.....	7
multi point entry.....	7, 9
passive entry.....	10
single point entry.....	7, 9
transmitter effects on medical devices.....	10
USB devices	
connecting multiple devices.....	133
Used engine oil.....	184
Using adaptive cruise control.....	105
Using cruise control.....	104
Using the parking aids.....	141
Using the spare tire	
important information.....	237
Using the touch screen.....	120
Using wheel chocks.....	237
V	
Valet mode.....	122
deselecting.....	122
Vehicle alarm.....	182
Vehicle battery	
battery monitoring system.....	210
connecting jump leads.....	207
effects of disconnection.....	210
removing.....	209
replacing.....	209
warning symbols.....	206
Vehicle battery care.....	206
Vehicle cleaning	
air bag covers.....	198
alloy wheels.....	196
automatic car wash.....	195
engine compartment.....	195
interior.....	196–197
rear screen.....	196
sunroof.....	196
washer jets.....	199
Vehicle data recording.....	240
Vehicle loading tire pressures.....	229
Vehicle recovery	
front towing eye.....	238
rear towing eye.....	239
steering column lock.....	10
transporting the vehicle.....	238
Vehicle testing on rolling roads.....	183
VIN number.....	241
Voice control.....	169

- navigation POI categories.....169
- Volume
 - telephone.....154
- W**
- Warning lamps.....52, 55
 - ABS.....54
 - ACC follow mode.....55–56
 - adaptive front lighting system (AFS).....53
 - air bags.....44, 53
 - automatic speed limiter.....54
 - battery charge.....52
 - brake.....52, 54
 - critical warning message.....52
 - cruise control.....55
 - DSC active.....54
 - engine/transmission.....54
 - engine temperature.....53
 - external temperature.....55
 - forward alert.....55
 - gear shift warning lamp.....55
 - headlamp high beam.....56
 - high beam assist.....55
 - intelligent speed limiter.....55
 - intelligent stop/start (green).....56
 - lamp test.....52
 - lane departure (green).....56
 - lane departure (red).....53
 - low fuel.....55
 - low oil pressure.....53
 - parking brake.....53
 - progress control system.....55
 - rear fog lamps.....55
 - seat belt.....53
 - side lights.....56
 - tire pressure monitoring system (TPMS).....55
 - turn signals.....56
- Warning messages.....48
- Washer jets.....199
- Washer reservoir
 - capacity.....245
- Washers.....62
 - fluid specification.....205
- fluid top up.....205
- headlamps.....64
- Washing
 - automatic car wash.....195
 - exterior paintwork.....195
 - removing grease.....196
 - removing stains.....197
 - removing tar.....196
 - soft top.....196
- Web browsing
 - InControl connection.....174
- Weights
 - gross vehicle weights.....246
 - roof load.....246
 - roof rack weight.....246
 - vehicle weights.....246
- Wheel changing
 - important information.....237
 - recommended process.....234
 - safety warnings.....232
 - spare wheel.....236
 - temporary spare wheel.....237
 - tilt sensor.....234
 - use of spare tire.....237
- Wheel chocks use.....237
- Wheels and tires
 - age degradation.....223
 - changing a tire.....230
 - flat spots.....223
 - load limit.....227
 - replacements.....222
 - temporary use spare.....230
 - tire care.....219
 - tire degradation.....223
 - tire glossary of terms.....226
 - tire grading system.....225
 - tire markings.....218
 - tire pressure label.....220
 - tire pressure monitoring system (TPMS).....228
 - tire pressures.....220
 - tire speed ratings.....219
 - tire temperature.....226
 - tire tread wear.....225

TPMS warning lamp.....	55
traction devices.....	224
uniform tire quality grading.....	225
valves.....	222
winter tires.....	223
Wheel spin.....	89
Where to	
navigation system.....	163
Wi-Fi	
InControl connection.....	174
Windows	
anti-trap protection.....	75
operation.....	74
reset.....	193
side window blinds.....	76
solar attenuating.....	76
sunroof reset.....	193
Winter park position.....	192
Winter tires.....	223
Wipers.....	62
Wipers and washers.....	62
drip wipe.....	64
fluid level.....	205
rain sensor.....	63
speed-dependent mode.....	64
Wireless technology	
Bluetooth.....	156

X

Xenon headlamps.....	187
----------------------	-----