



BY APPOINTMENT TO  
HER MAJESTY QUEEN ELIZABETH II  
MANUFACTURERS OF DAIMLER AND JAGUAR CARS  
JAGUAR CARS LIMITED COVENTRY



BY APPOINTMENT TO  
HER MAJESTY QUEEN ELIZABETH  
THE QUEEN MOTHER  
MANUFACTURERS OF DAIMLER AND JAGUAR CARS  
JAGUAR CARS LIMITED COVENTRY



BY APPOINTMENT TO  
HIS ROYAL HIGHNESS THE PRINCE OF WALES  
MANUFACTURERS OF DAIMLER AND JAGUAR CARS  
JAGUAR CARS LIMITED COVENTRY

## Vehicle Care Handbook

**JAGUAR CARS LIMITED** as manufacturers, are dedicated to the design and production of vehicles which meet the expectations of the world's most discerning purchasers.

To complement the features, systems and technology of your new vehicle we have produced this Vehicle Care Handbook. In it we have undertaken to provide information on vehicle care and maintenance to enable you to obtain lasting pleasure and reliability from your vehicle.

The information contained herein applies to a range of vehicles and not to a specific vehicle. For the specification of a particular vehicle, owners should consult their Jaguar Dealer.

The Manufacturer reserves the right to vary its specifications with or without notice, and at such times and in such manner as it thinks fit. Major as well as minor changes may be involved in accordance with the Manufacturer's policy of constant product improvement.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form, electronic, mechanical, photocopying, recording or other means without prior written permission from the Service Division of Jaguar Cars Limited.

# Contents

---

## 1. Introduction

General Information . . . . .	1-1
The Jaguar Diagnostic System . . . . .	1-1
Safety Precautions . . . . .	1-3
Safety, Warning and Caution Labels. . . . .	1-5
General Precautions . . . . .	1-6
Used Engine Oil. . . . .	1-7
Hydraulic Fluids . . . . .	1-7
Hood Release Control . . . . .	1-8

## 2. Cleaning

Introduction . . . . .	2-1
Exterior Care . . . . .	2-1
Interior Care . . . . .	2-4

## 3. Routine checks

Introduction . . . . .	3-1
Regular Checks . . . . .	3-1
Reservoir and Dipstick Locations. . . . .	3-2
Checking and Replenishment . . . . .	3-3
Check/Top Up Engine Oil Level. . . . .	3-3
Checking Coolant Level. . . . .	3-3
Check/Top Up Windscreen Washer/ Powerwash Reservoir . . . . .	3-4
Check/Top Up Brake Fluid Reservoir . . . . .	3-5
Check/Top Up Power Steering Fluid Reservoir. . . . .	3-5
Cooling System . . . . .	3-6
Engine Anti-freeze . . . . .	3-6
Engine Block Heater . . . . .	3-6
Recommended Engine Oil . . . . .	3-7
Capacities . . . . .	3-8

## 4. Roadside emergency service

Introduction . . . . .	4-1
Temporary-use Spare Wheel (where fitted) . . . . .	4-1
Spare Wheel and Jacking Equipment . . . . .	4-1
Spare Wheel Stowage . . . . .	4-2
Wheel Changing and Jacking . . . . .	4-2
Fitting the Spare Wheel . . . . .	4-7
Emergency Starting . . . . .	4-8
Vehicle Recovery . . . . .	4-10
Fuses and Fuse Boxes . . . . .	4-12
Fuse Box Locations . . . . .	4-13
Fuse Ratings and Circuits . . . . .	4-16
Control Modules – Identification and Location . . . . .	4-21
Relay Identification and Location . . . . .	4-22

## 5. Vehicle maintenance

Introduction . . . . .	5-1
Regular Servicing . . . . .	5-1
Tyres . . . . .	5-1
Care of Wheels . . . . .	5-4
Battery . . . . .	5-6
Generator . . . . .	5-6
Bulb Renewal . . . . .	5-9
Bulb Chart . . . . .	5-16
Windscreen Wiper Blades . . . . .	5-17
Windscreen Washers . . . . .	5-18

## 6. Specifications

Vehicle Data . . . . .	6-1
Weights (Approximate) . . . . .	6-2
Dimensions (Coupe and Convertible) . . . . .	6-4
Wheel/Tyre Data . . . . .	6-5
Fuel Requirements . . . . .	6-8

## 7. Accessories

Electrical Accessories . . . . .	7-1
Electrical Accessory Supply Sockets . . . . .	7-1
Earth Points . . . . .	7-1

A comprehensive index is located at the back of this book.

