

## Voice command synonyms

If preferred, the synonyms described in the following table can be used in place of the primary or preferred word in the voice commands described on the previous page. When a synonym or alternative phrase is used, the voice system will feedback the primary version of the command and not the phrase spoken by the user.

	Primary word	Synonyms
All Commands	Info	Information
	Seek	Search
	Phone	Telephone
	Navigation	Map
	No	Cancel
Radio	Play	On
	Tune	Select, except RADIO TUNE <i>nametag</i>
Tape	Tape	Cassette
	Play	On
	Reverse	Change Side

Voice command synonyms (continued)

	Primary word	Synonyms
Changer/CD/MD	Play	On (for CHANGER/CD/MD PLAY command only)
	Play	Select (for disc and track commands only)
	Mix	Shuffle/Random
Changer	Changer	CD Changer
	Disc	CD
Phone	Redial	Recall
Climate Control	Climate Control	Climate
	Defrost	Demist
Navigation	Clear	Delete
Display	Display	Screen
Television	Television	TV