Maintenance must be carried out at intervals not to exceed 26,000 kilometres or 1 year, whichever occurs first. Should the vehicle have a high proportion of short journeys or operate in severe conditions, Land Rover recommends that the maintenance procedures be performed at intervals not to exceed six months.

Please refer to Owner's Handbook for Service Recommendations if vehicle is used extensively off-road or under severe conditions.

	Maintenance Interval – whichever occurs first (based on expected vehicle display).									
Interval: Kilometres x 1,000	26	51	77	102	128	154	179	205	230	256
SERVICE Interval: Years	1	2	3	4	5	6	7	8	9	10
Check for and complete all open Recall and/or Service Actions	●	●	●	●	●	●	●	●	●	●
Reset Service Interval and Engine Oil Level indicators	●	●	●	●	●	●	●	●	●	●
Check wiper blades condition; operation of washer/wiper system	●	●	●	●	●	●	●	●	●	●
Check & top up underhood fluid levels	●	●	●	●	●	●	●	●	●	●
Check for underhood / under vehicle fluid leaks	●	●	●	●	●	●	●	●	●	●
Check all tire pressures, condition, tread depth, signs of uneven wear, and suitability	●	●	●	●	●	●	●	●	●	●
Inspect for brake pad wear; check disc condition on pad change	●	●	●	●	●	●	●	●	●	●
Replace engine oil and filter	●	●	●	●	●	●	●	●	●	●
Replace interior air filter		●		●		●		●		●
Replace brake fluid			●			●			●	
Replace spark plugs – Ingenium I4 2.0L				●				●		
Replace engine air cleaner element(s)				●				●		
Replace rear locking differential oil				●				●		
Replace spark plugs – V6 3.0L S/C					●					●
Replace all flexible brake hoses						●				
Replace Supercharger drive belt – V6 3.0L S/C									●	

	Maintenance Interval – whichever occurs first (based on expected vehicle display).									
Interval: Kilometres x 1,000	**26**	**51**	**77**	**102**	**128**	**154**	**179**	**205**	**230**	**256**
SERVICE **Interval: Years**	**1**	**2**	**3**	**4**	**5**	**6**	**7**	**8**	**9**	**10**
Replace accessory drive belt									●	
Replace front differential oil									●	
Replace transmission fluid and filter									●	
Replace transfer case oil									●	
Replace rear non-locking differential oil									●	
Replace engine coolant										●
Perform comprehensive road test; check operation of all vehicle features	●	●	●	●	●	●	●	●	●	●
Fault lamps illuminated? If 'yes', use Jaguar Land Rover-approved diagnostic tool for diagnosis/repair	●	●	●	●	●	●	●	●	●	●
Report any unusual features of vehicle condition and additional work required	●	●	●	●	●	●	●	●	●	●