
MAP SCREEN



1. Compass (set to North is up). Touch to toggle between this and the small compass which always indicates north (**12**).
2. Zoom and scale display.
3. Distance display.
4. Menu, touch to access Main menu, see **113, MAIN MENU**.
5. Screen mode selection: Touch to select alternative screen options (split screen option shown above), see **117, SCREEN MODES**
6. Current street location.
7. POI symbol, see **120, POINTS OF INTEREST (POI)**.
8. Split screen.
9. TMC symbol, see **123, RDS-TMC ICONS**.
10. Current vehicle position and direction of travel.
11. Next direction display.
12. Compass, always indicates north.
13. Message area.
14. **GPS** (Global Positioning System), with red arrow indicates a signal is not being received.
15. **TMC** (Traffic Master Channel), with red arrow indicates a signal is not being received.