8. Side bolster support adjustment.

To adjust the seats, the Jaguar Smart Key must be in the vehicle and the ignition turned on.

If an obstruction is encountered while the seat is in motion, the seat will stop moving and further movement will be restricted until reset.


To reset the seat:

1. Remove the obstruction.

2. Adjust the seat to the point where movement is restricted.


3. Press and hold the switch for at least 2 seconds to override the restriction.

SEATBACK TILT



To tilt the seat forward: remove the seat belt from the seat belt guide, see **18, USING SEAT BELTS**. Lift the lever and push the seatback forwards to allow easy access. The seatback will latch when returned to the up-right position. Make sure that the seat belt is returned to the seat belt guide.

DRIVING POSITION MEMORY



1. Memory presets.

2. Memory set button.

Once you have adjusted the driver's seat, steering column (see **16, ADJUSTING THE STEERING WHEEL**) and exterior mirrors (see **38, EXTERIOR MIRRORS**), the vehicle can memorise these settings using the driver memory buttons.

Once the passenger seat has been adjusted as desired, these settings can be memorised using the passenger memory buttons.

1. Press the memory set button to activate the memory function (the red indicator will illuminate for 5 seconds).

2. While the red indicator is illuminated, press one of the preset buttons within the 5 seconds to memorise the current settings. For the driver's settings, **MEMORY 1 (2 or 3) SETTINGS SAVED** will be displayed on the message centre accompanied by an audible chime to confirm the settings have been memorised.