USER SETTINGS

A number of user settings can be made from this menu.

From the **Navigation Setup** menu, select **User Settings**.

Touch the arrow buttons to scroll through the list. Touch to highlight the options required (light blue is not selected, dark blue is selected).

The **Text Size on the MAP** and **Keyboard Layout** options have more than one setting. Touch to toggle between the settings. The current setting is shown in a box alongside the relevant button.

When the User Settings are as required, select **OK**.

LANGUAGE SELECTION

It is possible to change the language used on the navigation display screens. This does not affect the navigation voice language.

From the Navigation Setup menu, select **Language Selection**, see **113, NAVIGATION SETUP**.

Use the arrow buttons to scroll through the list. Touch to select the required language. The display returns to the Navigation Setup menu.

MEASUREMENT UNITS

Distances shown on the screen and given in voice guidance, are either in metric units (kilometres and metres) or in imperial units (miles and yards) and can only be changed from the vehicle touch-screen menu, see **52, VEHICLE SETTINGS**.

SEARCH AREA

Some map databases are divided into counties, or in the case of some larger countries, into areas of countries, called Search areas. When setting a route, the destination (or waypoint) being entered must be in the currently selected search area.

The first time the navigation system is used, the driver should confirm that the correct country/area has been selected. Once set, it will remain correct for all future use, unless either the battery is disconnected, or a destination in an alternative search area is entered.

To change the search area, select **Search Area** from the **Destination Entry** menu. The currently selected search area is shown highlighted on the map.

Select the search area (country) relevant to your journey, from the list of available areas.