To connect a different paired phone to the vehicle, follow the steps below:

1. Select **Settings** on the Digit Dial screen, see **108, TELEPHONE SYSTEM OVERVIEW**.
2. A menu will appear. Select **Change phone**.
3. Identify and select your phone from the displayed list.
4. Once your phone is connected to the system, a confirmation message will be displayed before switching to the Digit Dial screen.

TELEPHONE SYSTEM ICONS


Connect. Use to send or accept a call and access last 10 calls list.


Disconnect. Use to end or reject a call.


No phone connected.


Phone signal strength indicator.


Phone battery level indicator.


Voicemail. Press and hold to dial the stored voicemail number.


Scroll bar up arrow. Use to scroll up lists of detected phones, calls or phonebook entries.


Scroll bar down arrow. Use to scroll down lists of detected phones, calls or phonebook entries.