ELECTRIC SEATS



Do not adjust the seat while the vehicle is moving. Doing so could cause a loss of vehicle control and personal injury.

1. Cushion length adjustment.
2. Bolster adjustment (inflate/deflate).
3. Lumbar support adjustment.
   - Press the top of the button to raise.