CONFIGURABLE DYNAMICS



Vehicles with configurable dynamics, will allow the Dynamic driving mode settings to be configured via the Touch screen for selected characteristics, with a choice between Normal and Dynamic settings. Select extra features from the home menu screen. See **75, TOUCH SCREEN CONTROLS**.

1. Touch to display and adjust configurable settings when in Dynamic mode.
2. **Stopwatch**: Touch to display live timings and split timings.

   Note: *Up to 99 split times can be saved and reviewed.*

   Note: *When the* ***Press to split*** *soft key has been selected, it is disabled for 3 seconds while the split time is displayed.*
3. **G Meter**: Touch to display the current amount and direction of G Force.
4. **Pedal Graph**: Touch to display a brake and accelerator graph, or a live display.
5. Indicates status: **Dynamic** or **Normal**.
6. Touch to display a description of the function.
7. **Engine**: Touch to select the **Dynamic** or **Normal** setting.
8. **Steering**: Touch to select the **Dynamic** or **Normal** setting.
9. **Suspension**: Touch to select the **Dynamic** or **Normal** setting.
10. Displays which dynamic functions are selected.
11. **Gear Shift**: Touch to select the **Dynamic** or **Normal** setting.
12. **Factory Setup**: Touch to switch **on/off**.

13. **My Setup**: Touch to switch the user settings **on**/**off**.