tyre pressure monitoring system (TPMS).....54
Warning messages.....48
Washer jets.....215
Washer reservoir capacity.....264
Washers.....62
fluid specification.....223
fluid top up.....223
headlamps.....64
Washing
automatic car wash.....212
exterior paintwork.....212
removing grease.....213
removing stains.....214
removing tar.....213
soft top.....213
Water in fuel.....190
Web browsing
InControl connection.....173
Weights
gross vehicle weights.....265
roof load.....265
roof rack weight.....265
tow ball/hitch.....90
towing.....90
vehicle weights.....265
Wheel changing
important information.....255
locking wheel nuts.....255
recommended process.....252
safety warnings.....250
spare wheel.....254
temporary spare wheel.....254
tilt sensor.....252
use of spare tyre.....255
Wheel chocks use.....254
Wheels and tyres
age degradation.....240
changing a tyre.....244
checking the pressures after a repair.....248
flat spots.....240
Indian regulations.....242
pressures.....238
puncture repair.....246
puncture repair safety.....246
repair kit.....246
repair kit use.....247
repair procedure.....247
replacements.....239
snow chains.....241
temporary use spare.....244
TPMS.....243
TPMS warning lamp.....54
tyre care.....237
tyre speed ratings.....237
tyre wall markings.....236
valves.....239
winter tyres.....240
Wheel spin.....111
Where to
navigation system.....180
Wi-Fi
InControl connection.....173
Windows
anti-trap protection.....73
operation.....72
reset.....210
side window blinds.....74
solar attenuating.....74
sunroof reset.....210
Winter park position.....209
Winter tyres.....240
Wipers.....62
Wipers and washers.....62
drip wipe.....64
fluid level.....222
rain sensor.....63
speed-dependent mode.....63
Wireless technology
Bluetooth.....163

X

Xenon headlamps.....201