

1. **Hitch Assist**: Select **OFF** or **ON**. See **91, HITCH GUIDANCE**.
2. **Parking Guidance**: Select **OFF** or **ON**.
3. **Parking Aid Graphics**: Select **OFF** or **ON**.
4. **PDC Plan View**: Select **OFF** or **ON**.

The Rear camera display on the Touch screen will discontinue when either of the following apply:

- A forward gear is selected for longer than five seconds.
- A forward gear is selected and/or the vehicle's speed is greater than 18 km/h (11 mph).

REVERSE TRAFFIC DETECTION

The Reverse Traffic Detection (RTD) system is a supplement to, not a replacement for, safe driving, good observation and use of the exterior and rear-view mirrors.

Note: *RTD is automatically disabled when a trailer is connected and when Park assist is active.*

In addition to the functionality provided by the Rear camera, the RTD system provides a warning to the driver of any moving vehicle, at either side, that may pose an accident risk during a reversing manoeuvre.



1. The amber warning icon flashes in the relevant exterior mirror and an audible warning tone is emitted to indicate the presence of a moving vehicle.
2. When RTD is disabled, an amber dot displays in both exterior mirrors.
3. The Rear camera screen, or the Parking aid screen, displays a warning icon on the relevant side(s) of the screen.

To switch between the Rear camera and the Parking aid screen, touch the camera image or the **Cameras** icon, accordingly.

The system can be enabled or disabled via the Instrument panel menus. See **47, INSTRUMENT PANEL MENU**.