bulb changing....200
condensation....58
courtesy delay....57
daytime running lamps....57
driving abroad....58
halogen bulbs....202
high beam assist....57
high beam assist warning lamp....54
high beam warning lamp....55
levelling....58
warning lamp (AFS)....52
washers....64
xenon....201
Head restraints
front seats....26
rear seats....26
Head up display....50
Heated seats....80
Heated steering wheel....29
Heating and ventilation....78
air quality sensor....80
automatic recirculation....80
front....78
fuel burning heater....81
heated and cooled seats....80
heated seats....80
rear....85
remote control batteries....84
timed climate remote controls....83
using the remote control....83
Heating and ventilation settings....79
High beam assist....57
Hill start assist....117
Hitch guidance cameras....91
Homelink....70
assistance....71
erase all programming....71
programming....70
programming a single button....71
programming the garage door opener....70

I

Ignition
rolling re-start....103
switching on....102
InControl
apps....174
overview....169
protect....169
remote premium....171
secure....173
wi-fi connection....173
Indicators warning lamp....54
Information messages....48, 51
Infotainment
connecting a media device....156
connecting multiple devices....159
licensing....160
media controls....151
pairing and connecting a device....159
playing a portable device....159
portable media
connections....156
controls....158
radio controls....154–155
settings....152
touch screen
care....76
extra features....77
operating....76
Instrument panel....47, 215
display units....49
fuel range....49
head up display....50
lamp test....51
menu....47
driving features....47
instrument display....47
trip computer....47
vehicle set-up....47
recommended tyre pressures....244
service indicator....49
trip computer....48
trip distance....49
tyre pressure check....243
warning lamps....51
warning messages....48