diesel fuel....187
oil level....217
petrol fuels....186
running-in....196
specifications....262
starting
keyless start backup....103
switching off....102
Engine/transmission warning lamp....53
Engine compartment
fluid filler locations....216
Engine compartment cleaning....212
Engine covers
refitting....200
removal....199
Engine oil
capacity....264
Engine starting....102
failure to start....104
Engine temperature warning lamp....51
Entering the vehicle
entry and exit mode....29
global opening....8
keyless entry....9
luggage compartment....10
passive entry....9
tailgate operation....10
unlocking mode....8
Ethanol....186
Event data recording....258
Exhaust filter....197
Exhaust fluid
diesel....188
Exiting the vehicle
arming the alarm....19
closing mislock....18
door locks and release levers....18
double locking....14
emergency locking....19
full alarm....15
global closing....17
interior locks....18
keyless locking....15
lock confirmation....14
passive arming....16
passive locking....16
perimeter alarm....15
single locking....14
Exterior cleaning....212
Exterior lamps
bulb changing....200
Exterior mirrors
electric....65
manual....65
mirror dip when reversing....66
External temperature
warning lamp....53
Extinguisher....211
Extra features....77


# F


Fatigue alert....130
Fire extinguisher....211
Flat spots....240
Fluids
brake
check....221
specification....222
top up....222
capacities....264
clutch check....221
coolant
specification....220
top up....220
engine oil
check....217
filler locations....216
oil
top up....219
specifications....263
washer fluid....223
check....222
specification....223
Fog lamps
warning lamps
rear....54
Follow
override....139