


Front seats

ELECTRIC SEATS



SJ1679

⚠ WARNING

Do not adjust the seat while the vehicle is moving. Doing so could cause loss of vehicle control and personal injury.

1. Seat back angle adjustment.

2. Lumbar support adjustment.

3. Cushion length adjustment.

4. Fore and aft adjustment.

5. Cushion front tilt adjustment.

6. Seatback tilt, see 17, **SEATBACK TILT**.

7. Height adjustment.
8. Side bolster support adjustment.



To adjust the seats, the Jaguar Smart Key must be in the vehicle and the ignition turned on.

If an obstruction is encountered while the seat is in motion, the seat will stop moving and further movement will be restricted until reset.

To reset the seat:

1. Remove the obstruction.
2. Adjust the seat to the point where movement is restricted.
3. Press and hold the switch for at least 2 seconds to override the restriction.


SEATBACK TILT



SJ1680

To tilt the seat forward: remove the seat belt from the seat belt guide, see **23, USING SEAT BELTS**. Lift the lever and push the seatback forwards to allow easy access. The seatback will latch when returned to the up-right position. Make sure that the seat belt is returned to the seat belt guide.

DRIVING POSITION MEMORY



SJ1681

1. Memory presets.
2. Memory set button.

Once you have adjusted the driver's seat, steering column (see **21, ADJUSTING THE STEERING WHEEL**) and exterior mirrors (see **46, EXTERIOR MIRRORS**), the vehicle can memorize these settings using the driver memory buttons.

Once the passenger seat has been adjusted as desired, these settings can be memorized using the passenger memory buttons.

1. Press the memory set button to activate the memory function (the red indicator will illuminate for 5 seconds).
2. While the red indicator is illuminated, press one of the preset buttons within the 5 seconds to memorize the current settings. For the driver's settings, **MEMORY 1 (2 or 3) SETTINGS SAVED** will be displayed on the message center accompanied by an audible chime to confirm the settings have been memorized.

Front seats

A seat position can only be memorized during the 5 second period.

Any existing settings for a memory preset will be over-written when programming a memory position.

RECALLING A MEMORIZED POSITION

Press the appropriate memory preset button (for the driver's settings, **MEMORY 1 (2 or 3) SETTINGS RECALLED** will be displayed in the message center).

SITTING IN THE CORRECT POSITION

⚠ WARNING


Riding with a reclined seatback increases your chance of serious or fatal injuries in the event of a collision or sudden stop. The protection of your restraint system (seat belts and air bags) is greatly reduced by reclining your seat. Seat belts must be snug against your hips and chest to work properly. The more the seatback is reclined, the greater the chance that an occupant's hips will slide under the lap belt or the occupant's neck will strike the shoulder belt. Drivers and passengers should always sit well back in their seats, properly belted, and with the seatbacks upright.

⚠ WARNING

Never adjust the driver's seat while the vehicle is moving. Any sudden or unexpected movement of the seat could cause you to lose control of the vehicle resulting in an accident.

⚠ WARNING

Do not sit or lean unnecessarily close to the air bag. An inflating air bag can cause serious injury or even death. Always fasten your seat belt properly and position the seat so that you can sit as far back as possible from the air bag and still comfortably reach all controls.



E132389

The seat, head restraint, seat belt and air bags, all contribute to the protection of the user. Correct use of these components will give you greater protection, therefore you should observe the following points:

1. Sit in an upright position with the base of your spine as far back as possible and the seat back reclined no more than 30 degrees.
2. Do not move the driver's seat too close to the steering wheel. Ideally, a minimum distance of 10 inches (254 mm) is recommended between the breastbone and the steering wheel air bag cover. Hold the steering wheel in the correct position with your arms slightly bent.
- Adjust the head restraint so that the top of the head restraint is above the center line of the head.

- Position the seat belt so that it is mid-way between your neck and your shoulder. Fit the strap tightly across your hips, not across your stomach.
- Ensure that your driving position is comfortable and enables you to maintain full control of the vehicle.