

For more information, visit the InControl section of the www.jaguarusa.com website.

Jaguar Assistance Breakdown Call



Located in the overhead console.

See **242, DRIVER CONTROLS**.

In the event of a breakdown, press and release the button cover to reveal the button. The button will be illuminated by a white LED. Press the button for 2 seconds to make a direct call to Jaguar Assistance. Also, the vehicle's details and the location will automatically be supplied to them.

When a call is initiated, the button will flash amber and will be constantly illuminated amber during the call.

Push the button cover back into place, after use.

Jaguar SOS Emergency Call



Located in the overhead console.

See **242, DRIVER CONTROLS**.

Note: The Jaguar SOS Emergency Call feature should only be used in the event of a severe accident, or in the event that personal safety or security is at risk.

Press and release the button cover to reveal the button. The button will be illuminated by a red LED. Press the button for 2 seconds to make a direct call to the emergency services. Also, the vehicle's details and the location will automatically be supplied to them.

When a call is initiated, the button will flash amber. The button will be constantly illuminated amber during a call.

Push the button cover back into place, after use.

Note: In the event that a severe crash is detected, the Jaguar SOS Emergency Call will be automatically triggered.

Note: If the vehicle is traveling in a different country, the Jaguar SOS Emergency Call will still connect, however, the vehicle's location and the vehicle's details may not be automatically sent.

This feature has 2 backup batteries that will maintain full system operation, in the event that the vehicle's battery is disconnected or disabled.

Note: The backup batteries will be maintained as part of the vehicle's servicing schedule, as carried out by a Dealer/Authorized Repairer.

If a fault is detected with the Jaguar SOS Emergency Call system, then the **SOS Limited** message will be displayed in the Message center. If this occurs, the vehicle can still be driven, but consult a Dealer/Authorized Repairer at the earliest opportunity.

INCONTROL SECURE

InControl Secure provides a stolen vehicle tracking service. In the event that the vehicle has been tampered with, or moved without your consent, you will be contacted by the InControl Secure Monitoring Center. Alternatively, use the InControl Remote Smartphone App, or the phone number on the InControl website, to contact the InControl Secure Monitoring Center.

When the vehicle is being serviced or repaired, InControl must be set to **Service mode**. This can be done by using the InControl Remote Smartphone App, or via the InControl website.

If the vehicle is being transported, InControl must be set to **Transport mode**. Again, this can be done by using the InControl Remote Smartphone App, or via the InControl website.

Failure to set Service mode or Transport mode could trigger a false theft alert.

Note: When set, Service or Transport mode should be updated every 10 hours, or more frequently, if required.