

**Note:** It remains the responsibility of the driver to know the location of the vehicle and to make sure that the vehicle is secured.

- The **Remote Climate** screen allows the engine to be started remotely (for vehicles with an automatic transmission), and run, for up to 30 minutes, to provide a comfortable temperature inside the cabin in advance of the driver entering the vehicle.

Remote climate will not function if any of the following conditions exist:

- The vehicle's fuel level is low.
- The vehicle's battery charge level is low.
- The vehicle is not locked.
- A window, door, bonnet, or the luggage compartment is open.
- The engine has been manually started.
- A system error with any required vehicle system.
- A theft has been detected.
- The vehicle's alarm is sounding.
- A crash event has been detected.
- The hazard warning lamps are switched on.
- The automatic transmission is not in Park (P).
- The brake pedal is pressed.

**Note:** Some markets may prohibit the use of a remote engine start. It remains the responsibility of the driver to know if this function can legally be used.

**Note:** This feature is also available for vehicles fitted with a Timed climate system. If the vehicle's configuration (e.g., transmission or engine variant) does not support a remote engine start, or if the vehicle originated in a market with legal restrictions on a remote engine start, then the Timed climate system may be used to support the cabin's pre-conditioning.

- **Wake Up Timer:** The InControl Remote system on the vehicle, will shut down if the vehicle is not driven for 4 days. This is to conserve battery power. If for example, you are on vacation, or away on a business trip, then you can use the **Wake Up Timer** on the Smart Phone App. This feature will wake up the InControl Remote system on the selected date. Any date within a 30 day period can be chosen.

**Note:** Note: The **Wake Up Timer** cannot be set once the InControl Remote system has shut down. Once the **Wake Up Timer** is set, the InControl Remote system will shut down on the second day after the car was last driven, to preserve battery power for wake up.

## INCONTROL SECURE

InControl Secure provides a stolen vehicle tracking service. In the event that the vehicle has been tampered with, or moved without your consent, you will be contacted by the InControl Secure operating centre. Alternatively, use the InControl Remote Smartphone App, or the phone number on the InControl website, to contact the InControl Secure operating centre.

When the vehicle is being serviced or repaired, **Service Mode** must be enabled for InControl Secure. This can be done by using the InControl Remote Smartphone App, or via the InControl website. This will prevent automatic theft alerts being raised while the vehicle is being serviced.

If the vehicle is being transported, **Transport Mode** must be enabled for InControl Secure. This can be done by using the InControl Remote Smartphone App, or via the InControl website. This will prevent automatic theft alerts being raised while the vehicle is being transported.

**Note:** When set, Service or Transport Mode should be updated every 10 hours, or more frequently if required.