

After adjustment of the driver's seat, steering column and the exterior mirrors, the vehicle can memorise these settings using the driver's door memory buttons. See **27, ADJUSTING THE STEERING WHEEL** and **65, EXTERIOR MIRRORS**.

1. Press the memory set button (**M**) to activate the memory function. The LED indicator lamp will illuminate to confirm.
2. Press one of the preset buttons within 5 seconds to memorise the current settings. **MEMORY 1 (2 or 3) SETTINGS SAVED** will be displayed in the Message centre, accompanied by an audible chime to confirm the settings have been memorised.


A seat position can only be memorised during the 5 second period.

Any existing settings, for a previous memory preset, will be over-written when programming a new memory position.

RECALLING A MEMORISED POSITION

Press the appropriate memory preset button. **MEMORY 1 (2 or 3) SETTINGS RECALLED** will be displayed in the Message centre.

SITTING IN THE CORRECT POSITION



E145130



The driver and front seat passenger must not ride with the seat fully reclined.



Do not adjust the seat while the vehicle is moving.

The seat, head restraint, seat belt, and airbags, all contribute to the protection of the user.

Correct use of these components will give you greater protection, therefore, you should always observe the following points:

1. Sit in an upright position, with the base of your spine as far back as possible. To achieve optimum benefit of the seat belt in the event of an accident, do not recline the seat excessively.
2. Do not move the driver's seat too close to the steering wheel. Ideally, a minimum distance of 254 mm (10 inches) is recommended between the breastbone and the steering wheel airbag cover. Hold the steering wheel in the correct position, with your arms slightly bent.
3. Adjust the head restraint so that the top of the head restraint is the same height as the top of the head.
4. Position the seat belt so that it is midway between your neck and your shoulder. Fit the strap tightly across your hips, not across your stomach.

Make sure that your driving position is comfortable and enables you to maintain full control of the vehicle.