



USING VOICE CONTROL



E163216



1. Voice button: Press briefly to start a voice session. Press and hold to cancel a voice session.

Note: Audible feedback can be interrupted at any time by just giving the next command.

A voice session will cancel if a higher priority activity or warning appears on the Touch screen, or there is no user input for a sustained length of time.

2. Command list: Appears on the Touch screen, providing feedback and some example commands at each stage of the voice session. Say or select an available command.

When spoken instructions are understood, the system will show a related screen, allowing the voice session to be continued either manually or by voice. Available commands at each stage of the conversation are shown at the top of the screen in the command bar.

3. Touch to cancel the current voice session and continue manually.

The following commands can be spoken at any time to assist in the operation of Voice control:

- Help
- Cancel
- Go back
- Replay.

Note: The Voice system has been designed to recognise a number of languages. However, it cannot be guaranteed that the system will be compatible with every accent group within those languages. Please speak to your Retailer/ Authorised Repairer about testing the Voice system for compatibility with a particular accent group.

VOICE TUTORIAL

To listen to a tutorial detailing the operation of the Voice system:

1. Briefly press the Voice button to start a voice session.
2. Wait for the tone to sound, then say **Voice tutorial**.

Voice control

Alternatively, from the **HOME** screen, select **EXTRA FEATURES** followed by **Voice** and then **Tutorial**. See **176, VOICE SETTINGS**.

The Voice tutorial can be cancelled at any time. Cancel via the displayed pop-up, or by pressing and holding the Voice button.

Alternatively, briefly press the Voice button and say **Cancel**.

VOICETAGS

Voicetags enable the user to personalise the Voice system so that a single name can be used to call-up a phone number, radio station or TV channel.

To add a Voicetag:

1. Briefly press the Voice button to start a voice session.
2. Wait for the tone to sound and say **Store Phone voicetag**, **Store Radio voicetag** or **Store TV voicetag**.
3. For radio and TV, the user must be listening to the station or channel, they wish to create a voicetag for.

Alternatively, Voicetags can be managed via the Touch screen as follows:

1. From the **HOME** screen, select **EXTRA FEATURES**.
2. Select **Voice** and then **Voicetags**.
3. Select the system that the Voicetag is to activate (**Phone**, **Radio** or **TV**).

Follow the on-screen and audible instructions. See **176, VOICE SETTINGS**.

VOICE SETTINGS

The following features can be selected from **Voice**. See **104, EXTRA FEATURES**.

- **Commands**: View the categories and the example voice commands. Select the > icon to view alternative examples of saying the same command.
- **Voicetags**: View the categories. Select a category to manage the Voicetags for the chosen system. See **104, EXTRA FEATURES**.
- **Tutorial**: Select for detailed instructions. Cancel via the displayed pop-up, or by pressing and holding the Voice button. Alternatively, briefly press the Voice button and say **Cancel**. See **175, VOICE TUTORIAL**.

Select **Voice Settings** via the **SETTINGS** pop-up menu. The following settings are displayed:

- **Voice Command Confirmation**: Select **On/Off**.
- **Voice Feedback**: Select **On/Off**.
- **Voice Recognition**: Select from the list of available languages.

Note: Only available when the system's language is not supported by speech.

- **Feedback Accent**: Select from the list of available accents.

*Note: Only available when the **Voice Recognition** language is UK or US English.*

Alternatively:

- Briefly press the Voice button and say **Voice confirmation on** or **Voice confirmation off**.
- Briefly press the Voice button and say **Voice feedback on** or **Voice feedback off**.