Voice Control System

DEFINED VOICE COMMANDS

The voice control system only understands a number of pre-defined commands. These commands need to be given **exactly** word for word.

You can prompt the system to speak a selection of these commands by activating the system and giving the commands **'Phone'** and **'Help'**.

Telephone commands

Always speak the command '**Phone**' and wait for the system to respond 'Phone' before issuing one of the following commands.


- Dial number
- Redial
- Dial name
- Store name
- Play directory
- Delete directory
- Delete name
- Help

Telephone sub-commands

These commands are used in response to a prompt or question within a dialogue.

- Correction
- Delete
- Cancel
- Store
- Dial
- Yes
- No
- Repeat
- Numbers 0-9
- Double
- Treble/Triple

ACTIVATING THE SYSTEM



AS0106

Activate voice control by pressing and releasing the 'Telephone/Voice recognition' switch, an audible signal is heard (the audio system will mute if switched on). The audible signal indicates that the system is now waiting for a spoken input.

Before giving a new voice command - except during a dialogue - always press the 'Telephone/Voice recognition' switch.

Interrupting voice control

A command can be interrupted by speaking the word **'Cancel'** or by pressing the 'Telephone/Voice recognition' switch for at least 2 seconds (the audio system will return to the volume level set prior to the call, if switched on).

Note: *It is only possible to interrupt dialogues, in which it is possible to speak a text of your choice e.g. name, by pressing the steering wheel key.*

If you receive a telephone call while conducting a dialogue by voice control, the telephone mode will override voice control.