

DECLARATIONS OF CONFORMITY

Declaration of Conformity appropriate to the Directive 1999/5/EC (R&TTE)
Annex IV

Visteon Deutschland GmbH
Manufacturers,

Notified Body consulted: Cetecon ICT Services GmbH, Untertürkheimer Strasse 6-10, D-66117 Saarbrücken
ID-Number of Notified Body: 0682

declare under our responsibility that the product: **Immobiliser System Transceiver**

Type: **PATS XCVR Start Control Unit**

Telecommunications Terminal Equipment Radio Equipment

Immobiliser System Transceiver

Intended Purpose: **1**
Equipment Class

complies with the appropriate essential requirements of the Article 3 of the R&TTE and the other relevant provisions, when used for its intended purpose.


Health and Safety requirements contained in Article 3 (1) a)
EN 60 950: 2001 Information technology equipment - Safety --
EN 50 371: 2002, Generic standard to demonstrate the compliance of low power electronic and electrical apparatus with the basic restrictions related to human exposure to electromagnetic fields (10 MHz - 300 GHz) -- General public.

Protection requirements with respect to electromagnetic compatibility Article 3 (1) b)
EN 301 489-03 V1.4.1: 08/2002, Electromagnetic Compatibility and radio spectrum Matters (ERM); Electromagnetic Compatibility (EMC) standard for radio equipment and services, Part 3: Specific conditions for Short Range Devices (SRD) operating on frequencies between 9 kHz and 40 GHz.

Means of the efficient use of the radio frequency spectrum

Air interface specifications of the radio path contained in Article 3(2)
EN 300 330-1 V1.3.2: 12/2002 and **EN 300 330-2 V1.1.1: 06/2001**; Electromagnetic compatibility and Radio spectrum Matters (ERM); Short range devices (SRD); Radio equipment in the frequency range 9 kHz to 25 MHz and inductive loop systems in the frequency range 9 kHz to 30 MHz; Part 1: Technical characteristics and test methods and Part 2: Harmonized EN under article 3.2 of the R&TTE Directive.

Address:
Visteon Deutschland GmbH
Visteonstrasse 4 - 10
50170 Kerpen
Germany
URL: <http://www.visteon.com/eurange>


Roland Greff
Vice President Visteon Deutschland GmbH

CE 0682

Declaration of Conformity appropriate to the Directive 1999/5/EC (R&TTE)
Annex IV

Visteon Deutschland GmbH
Manufacturers,

Notified Body consulted: Phoenix Test-Lab, Königswinkel 10, D-32825 Blomberg
ID-Number of Notified Body: 0700

declare under our responsibility that the product: **RKE Transmitter**

Type: **TXREL**

Telecommunications Terminal Equipment Radio Equipment

Remote Keyless Entry System Transmitter

Intended Purpose: **1**
Equipment Class

complies with the appropriate essential requirements of the Article 3 of the R&TTE and the other relevant provisions, when used for its intended purpose.


Health and Safety requirements contained in Article 3 (1) a)
EN 60 950: 2001 Information technology equipment - Safety -- Part 1: General Requirements.
EN 50 371: 2002, Generic standard to demonstrate the compliance of low power electronic and electrical apparatus with the basic restrictions related to human exposure to electromagnetic fields (10 MHz - 300 GHz) -- General public.

Protection requirements with respect to electromagnetic compatibility Article 3 (1) b)
EN 301 489-01 V1.4.1: 08/2002, Electromagnetic Compatibility and radio spectrum Matters (ERM); Electromagnetic Compatibility (EMC) standard for radio equipment and services; Part 1: Common technical requirements.
EN 301 489-03 V1.4.1: 08/2002, Electromagnetic Compatibility and radio spectrum Matters (ERM); Electromagnetic Compatibility (EMC) standard for radio equipment and services; Part 3: Specific conditions for Short Range Devices (SRD) operating on frequencies between 9 kHz and 40 GHz.

Means of the efficient use of the radio frequency spectrum

Air interface specification of the radio path contained in Article 3(2)
EN 300 220-3 V1.1.1: 09/2000, Electromagnetic compatibility and Radio spectrum Matters (ERM); Short range devices (SRD); RKE equipment to be used in the 25 MHz to 1000 MHz frequency range up to 500 mW; Part 3: Harmonized EN covering essential requirements under article 3.2 of the R&TTE Directive.

Address:
Visteon Deutschland GmbH
Visteonstrasse 4 - 10
50170 Kerpen
Germany
URL: <http://www.visteon.com/eurange>


Roland Greff
Vice President Visteon Deutschland GmbH

CE 0700

SIEMENS VDO
A U T O M O T I V E

SiemensVDO Automotive AG · P.O. Box 10 09 43 · D-93009 Regensburg

Name: **Dagmar Köhler**
Department: **Product Development Laboratory**
Tel.: **+49(0)941 7900-6000**
Fax: **+49(0)941 7900-136659**
E-Mail: **dagmar_koehe@siemens.com**
Internet: **www.siemensvdo.de**
Our Ref.: **Doc_5HWK49066.doc**
Date: **03/09/2005**

Declaration of Conformity with Directive 1999/5/EC (R&TTE Directive)

Manufacturer: **Siemens VDO Automotive AG
Body & Chassis Electronics**

Address: **Dep. SV C BC P2 RF TG
Siemensstrasse 12
D-93049 Regensburg
Germany**

Product type designation: **5HWK4 9066**

Intended use: **Radio frequency receiver used in vehicle locking/unlocking systems**

The product mentioned above complies with the essential requirements and other relevant provisions of Directive 1999/5/EC, when used for its intended purpose:

Health and safety pursuant to §3.1.a:

Electromagnetic compatibility pursuant to § 3.1.b:

Efficient use of spectrum pursuant to § 3.2:

The following marking applies to the above mentioned product:



Siemens VDO Automotive AG
Regensburg, 2005-08-03

Jean-Francois Tarabilla
Jean-Francois Tarabilla
Executive Vice President
Body and Chassis Electronics Operations

SiemensVDO Automotive AG
Body & Chassis Electronics
Helmut Mausch
Klaus Müller

Postal Address:
SiemensVDO Automotive AG
P.O. Box 10 09 43
D-93009 Regensburg
Tel.: +49(0)941790-0

SiemensVDO Automotive AG · Chairman of the Supervisory Board: Ernest C. Kuehnik · Managing Board: Frank Weisberg, Christian Jankowski, Klaus Eggert, Gerd Engelmann, Udo Bauer, Regensburg (DE), München (DE), Graz (AT), Chassis Electronics (Italy), Lincoln (US), USA

SIEMENS VDO
A U T O M O T I V E

SiemensVDO Automotive AG · P.O. Box 10 09 43 · D-93009 Regensburg

Name: **Regina Queigeler**
Department: **Product Development Laboratory**
Tel.: **+49(0)941 7900-3354**
Fax: **+49(0)941 7900-133 554**
E-Mail: **regina_queigeler@siemens.com**
Internet: **www.siemensvdo.de**
Our Ref.: **Doc_S120123.doc**
Date: **4/03/2004**

Declaration of Conformity with Directive 1999/5/EC (R&TTE Directive)

Manufacturer: **Siemens VDO Automotive AG
Body & Chassis Electronics**

Address: **Dep. SV C BC P2 RF TG
Siemensstrasse 12
D-93055 Regensburg
Germany**

Product type designation: **S120123**

Intended use: **Radio frequency transmitter used Tire Pressure Monitoring system**

The product mentioned above complies with the essential requirements and other relevant provisions of Directive 1999/5/EC, when used for its intended purpose:

Health and safety pursuant to §3.1.a:

Applied standard(s):
EN 60950; 2000

Electromagnetic compatibility pursuant to § 3.1.b:

Efficient use of spectrum pursuant to § 3.2:

The following marking applies to the above mentioned product:



Siemens VDO Automotive AG
Regensburg, 2004-03-04

Jean-Francois Tarabilla
Jean-Francois Tarabilla
Executive Vice President
Body and Chassis Electronics Operations

SiemensVDO Automotive AG
Body & Chassis Electronics
Helmut Mausch
Klaus Müller

Postal Address:
SiemensVDO Automotive AG
P.O. Box 10 09 43
D-93009 Regensburg
Tel.: +49(0)941790-0

SiemensVDO Automotive AG · Chairman of the Supervisory Board: Ernest C. Kuehnik · Managing Board: Frank Weisberg, Christian Jankowski, Klaus Eggert, Gerd Engelmann, Udo Bauer, Regensburg (DE), München (DE), Graz (AT), Chassis Electronics (Italy), Lincoln (US), USA

A

- ABS (Anti-lock braking system)
 - warning lamp 44
- ACC (Adaptive cruise control) 85
 - ASL (Active speed limiter) 90
 - ASL (Automatic speed limiter)
 - setting 90
 - suspending 90
 - automatic switch-off 87
 - driving hints 87
 - fault 88
 - follow mode 86
 - gap change 86
 - low speed switch-off 87
 - malfunction 88
 - override 87
 - resume follow mode 87
 - resume set speed 87
 - warning lamp 44
- ACC (adaptive cruise control)
 - operating 85
- Accessory wheels and tyres 156
- Active differential control 75
- Active head restraints
 - airbags 26
- Adaptive dynamics 75
- Adaptive front lighting system (AFS)
 - warning lamp 45
- AFS (Adaptive front lighting system) 31
- After a collision
 - pedestrian protection system 176
 - rollover bars 176
- Age degradation (tyres) 165
- Air conditioning
 - air quality sensor 56
 - auto 55
- Air quality sensor 56
- Airbags
 - active head restraints 26
 - deactivation indicator 28
 - deployment 27
 - module covers 143
 - service information 29
- SRS (Supplementary restraint system) 138
 - warning lamps 29, 45
- Alarm 10, 138
 - automatic relocking and arming 11
 - battery backed sounder 10
 - deactivating 11
 - passive arming 11
 - perimeter 10
 - sensor fault 11
 - tilt sensor 11
- Anchor points (ISOFIX) 23
- Antifreeze level check 148
- Anti-theft system 138
- Anti-trap protection
 - windows 37
- Approach lamps 31
- Arduous driving conditions 139
- ASL (Automatic speed limiter) 90
 - gap change 86
 - resuming 90
 - setting 90
 - suspending 90
 - warning lamp 45
- Audible warnings 46
- Audio
 - CD
 - controls 102
 - controls 91
 - DAB
 - reception 97
 - loading CDs 103
 - MP3 104
 - portable media
 - connections 99
 - controls 100
 - settings 92
- Audio system 142
- Auto mode (climate) 55
- Automatic gearbox 71
- Automatic locking 7
- Automatic switch off (ACC) 87
- Automatic switch off (cruise) 84

Index

- Auxiliary devices
 - connecting multiple devices. 101
- B**
- Battery
 - boost starting 159, 160
 - care 158
 - changing
 - timed climate remote 160
 - charging. 160
 - jump starting
 - connecting jump leads 159
 - disconnecting jump leads 160
 - monitoring system. 159
 - warning symbols 158
- Battery backed sounder. 10
- Beltminder 19
 - warning lamp 19, 43
- Bluetooth. 105
 - telephone
 - compatibility 105
 - icons 107
 - overview. 108
 - pairing 106
 - safety 105
- Bonnet
 - closing. 144
 - opening 144
- Boost starting 159, 160
- Brakes
 - ABS warning lamp 44
 - EBA (Emergency brake assist). 77
 - EBD (Electronic brake force distribution). 77
 - fluid
 - check 148
 - specification. 150
 - top up 150
 - handbrake 78
 - pedal travel 156
 - warning lamp. 43, 77
- BSM (Blind spot monitor)
 - detection beam issues. 88
- C**
- Calibration
 - navigation system 118
- Call volume 110
- Cameras
 - rear view 82
- Canceling guidance 118
- Capacities 155
- Carpets and mats 142
- Car-wash. 141
- CD player
 - controls. 102
 - loading discs 103
- Changing a fuse 168
- Changing the battery (timed climate) 160
- Charging the vehicle battery 160
- Chassis number 178
- Child restraints 20
 - check list. 21
 - positioning 22
- Child seats 20
 - check list. 21
 - Installing ISOFIX seats 23
 - ISOFIX anchor points 23
 - positioning 22
 - tether straps 24
- Cleaning
 - alloy wheels 140
 - carpets and mats. 142
 - convertible roof. 140
 - exterior 140
 - paintwork 141
 - glass 141
 - interior 141, 142
 - leather. 141
 - parking sensors 82
 - polishing 141
 - rear screen 141
 - removing grease 141

- removing stains 142
- removing tar 141
- underbonnet 141
- using a car-wash 141
- Climate control
 - auto 55
 - overview 56
 - recirculation 55
 - temperature 56
- Climate seats 56
- Clock 142
- Closing
 - alarm sensor faults 11
 - convertible roof 60
 - single locking 9
- Closing the bonnet 144
- Closing the luggage compartment 57
- Column lock 7
- Condensation (headlamps) 31
- Conformity declarations 180
- Consumption
 - urban cycle (fuel) 137
- Consumption (fuel) 137
- Controls
 - headlamps 30
 - steering wheel
 - set cruise speed 83
- Convertible roof
 - cleaning 140
 - closing 60
 - luggage separator 60
 - manual closing 64
 - manual re-set 62
 - opening 59
 - preparation for winter 143
- Coolant
 - checking the level 148
 - specification 148
 - top up 148
- Cruise control
 - ACC (Adaptive cruise control) 85
 - low speed switch-off 87
 - malfunction 88
 - operating 85
 - override 87
 - resume follow mode 87
 - resume set speed 87
 - automatic switch off 84
 - change speed 83
 - follow mode 86
 - operating 83
 - resume 83
 - setting vehicle speed 83
- D**
- DAB radio
 - controls 96
 - ensembles 98
 - reception 97
- Daily checks 138
- Data recording 176
- Daylight running lamps 31
- Declarations of conformity 180
- Deselecting valet mode 53
- Destination entry 117
 - map 120
 - motorway 121
 - navigation search area 115
 - postcode 120
 - previous 121
 - route preferences 117
- Detection beam issues 88
- Dialling a number 110
- Differential control 75
- Dimensions 154
- Direction indicators 30
 - warning lamp 45
- Disability modifications 138
- Door transceiver
 - entry gate 42
 - garage door opener 40
 - programming 40
 - programming a single button 41
 - rolling code device programming 41
- Double locking 9

Index

- Drive away locking 7
 - Drive control
 - operation 76
 - Driver controls 202
 - Driver information module
 - information messages 47
 - trip computer 48
 - warning lamps 43
 - warning messages 47
 - Driving
 - ACC (Adaptive cruise control) 85, 87
 - override 87
 - adaptive cruise control
 - automatic switch off 87
 - arduous conditions 139
 - ASL (Automatic speed limiter) 90
 - setting 90
 - before starting 176
 - controls 202
 - cruise control
 - automatic switch off 84
 - change speed 83
 - set speed 83
 - daily checks 138
 - DSC warning lamp
 - active 44
 - off 44
 - dynamic mode 74
 - EBA (Emergency brake assist) 77
 - EBD (Electronic brake force distribution) 77
 - forward alert 89
 - mirror dip when reversing 39
 - sitting correctly 14
 - wipers
 - rain sensor 34
 - DSC (Dynamic stability control)
 - switching between DSC and tracDSC 74
 - switching off 74
 - switching on 75
 - warning lamp
 - active 44
 - off 44
 - warning lamps 75
 - Dynamic mode 74
- ## E
- EBA (Emergency brake assist) 77
 - EBD (Electronic brake force distribution) 77
 - Electric seats
 - front 12
 - Electronic brake force distribution (EBD) 77
 - Electronic data 176
 - Electronic parking brake (EPB) 78
 - Engine
 - compartment
 - cleaning 141
 - fuse box 168
 - opening 144
 - overview 145
 - coolant level checking 148
 - engine compartment 145
 - engine malfunction warning lamp 44
 - failure to start 69
 - malfunction warning lamp 44
 - number 178
 - oil consumption 147
 - oil level check 146
 - oil level consumption 147
 - oil specification 147
 - specifications 152
 - starting 70
 - starting the engine 68
 - switching off 68
 - Ensembles (DAB radio) 98
 - Entering a postcode
 - navigation system 120
 - Entering the vehicle
 - entry and exit mode 16
 - keyless entry 6
 - Entertainment
 - CD
 - controls 102
 - DAB radio
 - controls 96

- portable media
 - connecting devices 99
 - connecting multiple devices..... 101
 - connections 99
 - controls 100
 - radio
 - controls 94
 - RDS (Radio data system) 95
 - touch screen 142
 - display icons 51
 - home menu 50
 - operating 51
 - system settings 52
 - touch screen care 51
 - Entry and exit mode 16
 - EPB (Electric parking brake) 78
 - Ethanol 134
 - Event data recording 176
 - Exiting the vehicle
 - door locks and release levers..... 9
 - global closing 10
 - keyless locking 10
 - Exterior cleaning 140
 - Exterior mirrors 38
 - External temperature display 56
 - Extinguisher 140
- F**
- Faulty alarm sensors 11
 - Filler flap 135
 - Fire extinguisher 140
 - First aid kit..... 140
 - Flat spots..... 165
 - Fluids
 - brake
 - check 148
 - specification..... 150
 - top up 150
 - capacities..... 155
 - coolant
 - specification..... 148
 - top up 148
 - engine oil
 - check..... 146
 - specification 147
 - fuel tank capacity 136
 - power steering
 - check..... 150
 - specification 151
 - specifications 152
 - washer
 - specification 151
 - top up 151
 - Fog lamps
 - warning lamp 44
 - Follow mode
 - entering..... 86
 - gap change 86
 - override..... 87
 - resume 87
 - suspending 90
 - Forward alert..... 89
 - Front parking aid
 - operation..... 81
 - system fault 82
 - Front towing eye 175
 - Fuel and refuelling
 - consumption..... 137
 - extra-urban cycle..... 137
 - urban cycle 137
 - ethanol 134
 - filler flap 135
 - fuel consumption
 - urban cycle 137
 - fuel specification 136
 - fuel system 139
 - methanol..... 134
 - MTBE (Methyl tertiary butyl ether) ... 135
 - octane rating 134
 - running out 135
 - safety precautions..... 134
 - tank capacity..... 136
 - Fuses
 - changing 168
 - engine compartment fuse box..... 168

Index

- locations 167
- luggage compartment fuse box 170
- Passenger compartment fuse box 169

- G**
- Garage door opener 40
 - entry gate 42
 - erase all programming 41
 - programming 40
 - a single button 41
 - rolling code device 41
- Gear selector 72
 - malfunction 72
- Gearbox
 - automatic 71
 - identification number 178
 - limp home mode 72
 - operation 76
 - selector 72
 - selector malfunction 72
 - temporary manual selection 72
 - winter mode 74
- Glass cleaning 141
- Global closing 10
- Global opening 7

- H**
- Handbrake 78
- Handling
 - adaptive dynamics 75
 - DSC warning lamp
 - active 44
 - off 44
 - dynamic mode 74
 - EBD (Electronic brake force distribution) 77
- Head restraints 15
 - active 26
- Headlamps
 - adaptive 31
 - AFS (Adaptive front lighting system) 31
 - approach lamps 31
 - condensation 31
 - controls 30
 - daylight running lamps 31
 - high beam warning lamp 45
 - warning lamp (AFS) 45
 - washers 35
 - wiper detection 31
- Heated screens 55
- Heated seats 56
- Heated steering wheel 16
- Heating and ventilation
 - auto 55
 - recirculation 55
- High beam
 - warning lamp 45
- Homelink 40
 - programming a single button 41
 - rolling code device programming 41

- I**
- Identifying the vehicle
 - transmission number 178
- Ignition
 - rolling re-start 70
 - switching off while moving 70
 - switching on 68
- Indicators 30
 - warning lamp 45
- Information messages 47
- Infotainment
 - CD
 - controls 102
 - DAB radio
 - controls 96
 - navigation
 - coordinates 120
 - POI (Points of interest) 118, 120
 - restore defaults 118
 - portable media
 - connecting devices 99
 - connecting multiple devices 101
 - connections 99
 - controls 100

- radio
 - controls 94
 - RDS (Radio data system) 95
 - telephone
 - last 10 110
 - pairing 106
 - phonebook 110
 - touch screen 142
 - display icons 51
 - home menu 50
 - operating 51
 - system settings 52
 - touch screen care 51
 - Instrument pack 142
 - Instrument panel
 - information messages 47
 - lamp test 43
 - trip computer 48
 - warning lamps 43
 - side lights 45
 - warning messages 47
 - Interior cleaning 141, 142
 - carpets and mats 142
 - Interval indicator 49
 - ISOFIX anchor points 23
 - ISOFIX seats
 - installing 23
- J**
- Jaguar Dealers
 - navigation system 121
 - Jaguardrive control
 - operation 76
 - Jump starting
 - connecting jump leads 159
 - disconnecting jump leads 160
- K**
- Keyless entry 6
 - Keyless locking 10
 - Keys
 - single locking 9
- L**
- Label locations 178
 - Lamp test 43
 - Lamps
 - condensation 31
 - controls 30
 - wiper detection 31
 - Leather cleaning 141
 - Licensing
 - telephone system 111
 - Lights
 - condensation 31
 - controls 30
 - Limp home mode 72
 - Loading the map DVD 112
 - Locking
 - alarm sensor faults 11
 - automatic relocking 11
 - confirmation 9
 - door locks and release levers 9
 - double locking 9
 - drive away 7
 - global closing 10
 - keyless 10
 - mislock 9
 - Locking and unlocking
 - alarm
 - perimeter 10
 - sensor faults 11
 - passive arming 11
 - single locking 9
 - unlocking 4
 - Locking column 7
 - Lubricants
 - specifications 152
 - Luggage compartment
 - closing 57
 - fuse box 170
 - opening 57
 - Luggage separator 60

Index

- M**
- Main menu
 - navigation 113
 - structure 114
 - Maintenance
 - blocked washer jets 139
 - boost starting
 - connecting jump leads 159
 - disconnecting jump leads 160
 - brake fluid check 148
 - capacities 155
 - changing a fuse 168
 - checking the tyre pressures 164
 - checking the tyre pressures after a repair 132
 - cleaning
 - polishing 141
 - removing grease and tar 141
 - removing stains 142
 - cleaning alloy wheels 140
 - cleaning glass 141
 - cleaning parking sensors 82
 - cleaning rear screen 141
 - closing the bonnet 144
 - convertible roof 140
 - coolant level checking 148
 - daily checks 138
 - engine compartment 145
 - exterior cleaning 140
 - fuse box (luggage compartment) 170
 - interior cleaning 141, 142
 - jump starting 159, 160
 - label locations 178
 - leather cleaning 141
 - lubricants and fluid specifications 152
 - paintwork repair 140
 - preparation for winter 143
 - smart key battery changing 8
 - weekly checks 138
 - Manual closing
 - convertible roof 64
 - Media
 - portable media
 - connections 99
 - Memory points
 - adding 119
 - navigation system 122
 - Memory seats
 - recalling a position 14
 - Message centre
 - trip computer 48
 - change display 48
 - range 48
 - Methanol 134
 - Minor paintwork damage repair 140
 - Mirrors
 - dip when reversing 39
 - Mirrors and windows
 - BSM (Blind spot monitor)
 - detection beam issues 88
 - exterior mirrors 38
 - Modifications for disabilities 138
 - Monitoring system (battery) 159
 - Motorway entry/exit 119
 - MP3 104
 - mpg 137
 - MTBE (Methyl tertiary butyl ether) 135
- N**
- Navigation
 - cancel guidance 118
 - declaration of conformity 128
 - destination entry 117
 - coordinates 120
 - map 120
 - motorway 121
 - postcode 120
 - previous destinations 121
 - route preferences 117
 - search area 115
 - start guidance 117
 - end user agreement 127
 - keyboard layout 115

- language selection 115
 - licenses 127
 - loading the DVD 112
 - main menu 113
 - main menu structure 114
 - map text size 115
 - measurement units 115
 - memory points 122
 - add 119
 - overview 112
 - POI (Points of interest) 120
 - quick POI selection 118
 - points of interest (POI)
 - categories 121
 - entry by category 121
 - entry by town 121
 - Jaguar Dealers 121
 - list button 122
 - search area 122
 - RDS-TMC 122
 - alternative routes 123
 - avoiding traffic events 123
 - dynamic navigation 123
 - on route events 124
 - RDS-TMC display 122
 - restore defaults 118
 - screen mode 116
 - screen modes 117
 - setting avoid points 119
 - settings
 - calibration 118
 - setup 113
 - stored locations 119
 - home 119
 - TMC
 - all traffic events 124
 - display 122
 - event icons 123
 - surveillance points 125
 - traffic on route 123
 - using TMC 123
 - user settings 115
 - vehicle position/direction 118
- O**
- Occupant safety
 - child seats
 - tether straps 24
 - seatbelts 143
 - seatbelt safety 17
 - warning lamp 19, 43
 - Octane rating 134
 - Oil
 - engine
 - consumption 147
 - level check 146
 - engine oil specification 147
 - used engine oil 139
 - One-touch operation (windows) 36
 - Opening
 - alarm sensor faults 11
 - bonnet 144
 - luggage compartment 57
 - Opening convertible roof 59
 - Overriding speed and follow mode (cruise) 87
- P**
- Paddle shift
 - temporary manual selection 72
 - Paintwork
 - cleaning 141
 - repair 140
 - Parking aid 81
 - rear view camera 82
 - sensor cleaning 82
 - system fault 82
 - Parking brake 78
 - Passenger compartment fuse box 169
 - Passive arming 11
 - Pedestrian protection system 176
 - after deployment 176
 - Perimeter alarm 10

Index

- Phone
 - bluetooth 105
 - call volume 110
 - changing connected phone 106
 - compatibility 105
 - dialling 110
 - icons 107
 - last 10 110
 - licensing 111
 - overview 108
 - pairing using mobile phone 106
 - pairing using touch screen 106
 - phonebook 110
 - safety 105
 - settings menu 109
 - POI (Points of interest) 120
 - navigation system 118
 - Points of interest (POI)
 - categories and sub-categories 121
 - entry by category 121
 - entry by town 121
 - Jaguar Dealerships 121
 - list 122
 - search area 122
 - Portable media
 - connecting devices 99
 - connecting multiple devices 101
 - connections 99
 - controls 100
 - Positioning child restraints 22
 - Power steering
 - fluid
 - check 150
 - specification 151
 - Preparation for winter 143
 - Pressure
 - checking 164
 - Pressures
 - checking
 - after a repair 132
 - tyres 162
 - winter tyres 165
 - Previous destinations
 - navigation system 121
 - Programming
 - garage door opener 40
 - erase all 41
 - Puncture repair kit 129
 - instructions for use 131
 - repair procedure 131
 - safety 129
 - Punctured tyres 164
- ## R
- Radio
 - controls 94
 - DAB ensembles 98
 - DAB reception 97
 - RDS (Radio data system) 95
 - Rain sensor 34
 - RDS (Radio data system) 95
 - RDS-TMC
 - all traffic events 124
 - navigation system 122
 - surveillance points 125
 - traffic event icons 123
 - traffic on route 123
 - Rear screen cleaning 141
 - Rear towing eye 175
 - Recalling seat memory position 14
 - Reception (DAB) 97
 - Recirculation 55
 - Recovery
 - towing eyes 175
 - transporting 175
 - Refuelling 135
 - octane rating 134
 - running out of fuel 135
 - safety precautions 134
 - Remote control
 - battery changing 8
 - care 7
 - system transmitters 157
 - Repairing paintwork damage 140

- Replacement tyres 164
 - Resetting the windows 140
 - Restarting the engine whilst moving 70
 - Restore default settings (navigation system) 118
 - Restraints (child) 20, 21
 - positioning 22
 - Resume speed and follow mode (ACC) 87
 - Resuming set speed (ASL) 90
 - Resuming set speed (cruise) 83
 - Reverse parking aid
 - operation 81
 - rear view camera 82
 - system fault 82
 - Rolling re-start 70
 - Rollover bars 29, 176
 - Rollover protection device (RPD) 29, 176
 - Running out of fuel 135
- S**
- Safety
 - fuel and refuelling 134
 - in the garage 139
 - seatbelts 17, 143
 - warning lamp 19, 43
 - sitting correctly 14
 - tyre care 162
 - used engine oil 139
 - using the telephone 105
 - warning triangle 140
 - Satellite navigation
 - overview 112
 - Screen modes (navigation system) 117
 - Screens (heated) 55
 - Seatbelts 143
 - beltminder 19
 - beltminder warning lamp 43
 - checks 17
 - safety 17
 - warning lamp 19, 43
 - Seats
 - child seats
 - tether straps 24
 - climate 56
 - electric
 - front 12
 - head restraints 15
 - heated 56
 - memory
 - recalling a position 14
 - seatbelts 143
 - safety 17
 - warning lamp 19, 43
 - Security 10
 - alarm 138
 - passive arming 11
 - perimeter 10
 - tilt sensor 11
 - automatic relocking and arming 11
 - battery backed sounder 10
 - deactivating the alarm 11
 - lock confirmation 9
 - sensor faults 11
 - steering column lock 7
 - Selecting valet mode 52
 - Selector fails to elevate 72
 - Sensors
 - security sensor faults 11
 - Service information
 - airbags 29
 - Service interval indicator 49
 - Servicing
 - interval indicator 49
 - Setting a destination (navigation) 117
 - Setting avoid points
 - navigation system 119
 - Setting cruise speed 83
 - Settings
 - navigation language 115
 - phone 109
 - vehicle 51
 - Setup
 - navigation system 113

Index

- Side lights
 - warning lamp 45
 - Silencing the alarm 11
 - Sitting correctly 14
 - Smart key
 - battery changing 8
 - care 7
 - single locking 9
 - transmitters 157
 - Snow chains 166
 - Specifications
 - brake pedal travel 156
 - dimensions 154
 - engine 152
 - engine number 178
 - engine oil 147
 - ethanol 134
 - fluids 152
 - washer 151
 - fuel 136
 - fuel tank capacity 136
 - label locations 178
 - lubricants 152
 - methanol 134
 - weights 153
 - wheel alignment 156
 - Speed limiter
 - setting 90
 - Speed-dependent wipers 34
 - SRS
 - Airbags 138
 - SRS (Supplementary restraint system)
 - airbag covers 143
 - airbag warning lamp 29, 45
 - child seat check list 21
 - child seat positioning 22
 - child seats 20
 - ISOFIX Anchor points 23
 - seatbelts (beltminder) 19
 - seatbelts (beltminder) warning lamp 43
 - Stability control
 - switching between DSC and tracDSC 74
 - switching off 74
 - switching on 75
 - tracDSC 74
 - switching between tracDSC and DSC 74
 - warning lamps 75
 - Starting
 - preparation 176
 - Starting navigation guidance 117
 - Starting the engine 68, 70
 - Steering column lock 7
 - Steering wheel
 - adjusting 16
 - column lock 7
 - controls
 - set cruise speed 83
 - heated 16
 - Stopping navigation guidance 118
 - Storage compartments 67
 - cup holders 67
 - front cubby box 67
 - glove box 67
 - rear armrest 67
 - Stored locations
 - avoid points 119
 - home 119
 - navigation system 119
 - store a memory point 119
 - Suspending ASL (Automatic speed limiter) 90
 - Switching off the engine 68
 - Switching off the ignition while moving 70
 - Switching on the engine 68
 - Switching on the ignition 68
- ## T
- Technical specifications
 - weights 153
 - wheel alignment 156
 - Telephone
 - bluetooth 105
 - call volume 110
 - changing the connected telephone 106
 - compatibility 105

- dialling 110
- icons 107
- last 10 110
- overview 108
- pairing 106
- phonebook 110
- safety 105
- settings 109
- Temperature (external) 56
- Temporary use spare wheel 174
- Tilt sensor 11
- Timed jet function 35
- Touch screen 142
 - CD
 - controls 102
 - display icons 51
 - home menu 50
 - navigation
 - POI (Points of interest) 120
 - operating 51
 - portable media
 - connecting devices 99
 - connecting multiple devices 101
 - connections 99
 - controls 100
 - system settings 52
 - telephone
 - last 10 110
 - pairing 106
 - phonebook 110
 - touch screen care 51
 - valet mode 52
 - vehicle settings 51, 52
 - Towing eyes 175
 - TPMS (Tyre pressure monitoring system) 79
 - tyre care 162
 - valves 164
 - warning lamp 45
 - tracDSC 74
 - warning lamps 75
 - Traction control
 - switching between DSC and tracDSC 74
 - switching off 74
 - switching on 75
 - tracDSC 74
 - switching between tracDSC and DSC 74
 - warning lamps 75
 - Traffic Master Channel (TMC) 122
 - Transmission
 - gear selector 72
 - identification number 178
 - limp home mode 72
 - operation 76
 - selector fails to elevate 72
 - temporary manual selection 72
 - winter mode 74
 - Transmission (automatic) 71
 - Transmitters
 - smart key 157
 - Transporting the vehicle 175
 - Trim
 - airbag covers (cleaning) 143
 - Trip computer 48
 - change display 48
 - range 48
 - Turning on the engine 68
 - Tyre pressure checking 164
 - Tyre pressure checking after repair 132
 - Tyre repair kit
 - repair procedure 131
 - Tyres
 - age degradation 165
 - changing 79
 - flat spots 165
 - pressures 162, 163
 - winter tyres 165
 - punctured 164
 - repair kit 129, 131
 - repair procedure 131
 - safety 129
 - replacements 164
 - snow chains 166
 - temporary use spare 79

Index

- TPMS (Tyre pressure monitoring system) 79
 - warning lamp 45
 - tyre care 162
 - valves 164
 - winter 165
- U**
- Underbonnet cleaning 141
 - Unlocking 4, 9
 - alarm sensor faults 11
 - entry and exit mode 16
 - global opening 7
 - keyless entry 6
 - passive arming 11
 - Urban cycle 137
 - Used engine oil 139
 - User settings
 - navigation 115
 - Using cruise control 83
- V**
- Valet mode 52
 - deselecting 53
 - Vehicle alarm 138
 - Vehicle battery care 158
 - Vehicle cleaning
 - alloy wheels 140
 - carpets and mats 142
 - exterior 140
 - interior 141, 142
 - parking sensors 82
 - rear screen 141
 - Vehicle data recording 176
 - Vehicle handling 75
 - Vehicle identification
 - transmission number 178
 - Vehicle position/direction
 - navigation system 118
 - Vehicle recovery
 - attaching the front tow eye 175
 - towing eyes 175
 - transporting the vehicle 175
 - Vehicle settings 51
 - valet mode 52
 - VIN number 178
 - Volume
 - telephone 110
- W**
- Warning lamps 43
 - ABS 44
 - ACC 44
 - adaptive cruise control 44
 - adaptive front lighting system 45
 - AFS 45
 - airbags 29, 45
 - ASL (Automatic speed limiter) 45
 - audible warnings and indicators 46
 - beltminder 43
 - brake 43, 77
 - DSC 44
 - engine malfunction 44
 - fog lamps 44
 - headlamp high beam 45
 - indicators 45
 - lamp test 43
 - parking brake 77
 - seatbelt 19, 43
 - side lights 45
 - stability control 75
 - TPMS (Tyre pressure monitoring system) 45
 - Warning messages 47
 - Warning symbols (battery) 158
 - Warning triangle 140
 - Washer jets
 - blockages 139
 - Washers
 - operating 34
 - timed jet function 35
 - windscreen 35
 - Washers (headlamps) 35

- Washing
 - exterior
 - paintwork 141
 - removing tar 141
 - interior
 - removing stains 142
 - polishing 141
 - removing grease 141
 - under the bonnet 141
 - Weekly checks 138
 - Weights 153
 - Wheels and tyres
 - accessory wheels and tyres 156
 - age degradation 165
 - changing a tyre 79
 - checking the pressures 164
 - checking the pressures after a repair . . 132
 - flat spots 165
 - pressures 162
 - puncture repair 129
 - safety 129
 - punctured 164
 - repair kit 129, 131
 - repair procedure 131
 - safety 129
 - replacements 164
 - snow chains 166
 - temporary use spare 79
 - TPMS (Tyre pressure monitoring system) 79
 - warning lamp 45
 - tyre care 162
 - tyre label 178
 - valves 164
 - wheel alignment 156
 - winter tyres 165
 - Windows 36
 - anti-trap protection 37
 - one-touch operation 36
 - reset 140
 - Windscreen wipers
 - speed-dependent mode 34
 - Windscreens (heated) 55
 - Winter mode 74
 - Winter tyres 165
 - pressures 165
 - Wipers
 - drip wipe 35
 - operating 34
 - Wipers and washers
 - fluid
 - specification 151
 - top up 151
 - operating 34
 - rain sensor 34
 - timed jet function 35
 - windscreen washers 35
 - wipers
 - speed-dependent mode 34
- X**
- Xenon headlamps
 - wiper detection 31