

The coolant level in the expansion tank should be checked at least weekly (more frequently in high distance or severe operating conditions).




**Always check the coolant level when the system is cold.**

Make sure the coolant level is maintained between the level indicator marks, as shown in the illustrations.

## Diesel engines



## Petrol engines



If coolant/steam is expelled from the pressure cap, or the level has dropped suddenly, or by a large amount, arrange for the vehicle to be examined by a qualified technician as soon as possible.

If the message **LOW COOLANT LEVEL** is displayed in the Message centre, stop the vehicle as soon as safety permits and top up the coolant reservoir with the recommended antifreeze/water mix.

If the Message centre displays the message **ENGINE OVERHEATING**, pull off the carriageway and allow the engine to idle for 5 minutes and then switch off the ignition for 10 minutes. Switch on the engine and, provided that the warning does not occur, continue your journey, avoiding harsh acceleration. Seek qualified assistance as soon as possible.

## TOPPING UP THE COOLANT



**Never remove the filler cap when the engine is hot.**



**Antifreeze is highly flammable. Do not allow antifreeze to come into contact with naked flames or other sources of ignition (e.g., a hot engine) - a fire may result.**



**Unscrew the filler cap slowly, allowing the pressure to escape before removing completely.**



When travelling in territories where the water supply contains salt, always make sure you carry a supply of fresh (rain or distilled) water. Topping up with salt water will cause serious engine damage.

Top-up to the upper level indicator mark. Use only a 50% mix of water and antifreeze. See **209, LUBRICANTS AND FLUIDS**.

**Note:** *In an emergency, if the approved antifreeze is unavailable, top-up the system with clean water, but be aware of the resultant reduction in frost protection. Do not top-up or refill with conventional antifreeze formulations. If in doubt, consult a qualified technician.*