

Note: The handle in the retracted flush position indicates a locked door or a vehicle speed above 5 mph (8 km/h).

9. Passive lock: Press the rear of the door handle to lock the vehicle. The door handle will retract to the flush position. See **15, LOCKING AND ARMING THE ALARM.**

Note: The handle in the deployed position indicates an unlocked door.

10. Emergency door unlock: If the Smart key and Passive entry fail to open the vehicle, insert the key blade into the slot behind the driver's door handle. Pull and hold the handle for access.

- To unlock, turn the key blade towards the front of the vehicle and release.

Note: If the security system is disarmed, both doors and the Luggage compartment will be unlocked. If the security system is armed, only the driver's door will unlock.

Note: If the vehicle is unlocked using the emergency key blade with the security system armed, the alarm will sound when a door is unlocked. To deactivate the alarm, press the unlock button on the Smart key or press the engine **START/STOP** button with the Smart key inside the vehicle.

Note: If the Smart key is not detected, **SMART KEY NOT FOUND REFER TO HANDBOOK** will be displayed in the Message center. See **82, KEYLESS START BACKUP.**

- To lock, turn the key blade towards the rear of the vehicle and release.

Note: This will lock both of the doors but will not arm the alarm.

SINGLE/MULTI-POINT ENTRY

When you press the unlock button, your vehicle will unlock in one of two ways:

1. Single-point entry: Unlocks the driver's door only. A second press is required to unlock the remaining doors and the tailgate.
2. Multi-point entry: Unlocks all of the doors, and the tailgate on the first press.

To change from Single to Multi-point entry (or vice versa), press both the lock and unlock buttons simultaneously for 3 seconds. The hazard warning lamps will flash twice to confirm the change.

This feature may also be set via the **Vehicle Settings** menu. See **42, INSTRUMENT PANEL MENU.**

Note: If, when the vehicle is unlocked, an audible warning is emitted, this will be a 'Mislock' error. There may be a fault with either of the alarm sensors. Consult with your Dealer/Authorized Repairer as soon as possible.

PASSIVE ENTRY

NOTICE

If a Smart key is lost, a replacement can be obtained and reprogrammed to the vehicle by a Dealer/Authorized Repairer. Notify a Dealer/Authorized Repairer as soon as a Smart key is lost or stolen and have the remaining Smart key(s) reprogrammed.

Passive entry allows the vehicle to be unlocked and disarmed by simply operating the door handle, provided the Smart key is within 3 feet (1 meter).