BLIND SPOT MONITOR

The Blind Spot Monitor (BSM) system is a supplement to, not a replacement for, a safe driving style and use of the exterior and rear-view mirrors. The system may not function under all speeds, weather and road conditions.

Please note that the BSM may not be able to give adequate warning of vehicles approaching very quickly from behind or vehicles that are being passed rapidly.

The BSM may not be able to detect all vehicles and may also detect objects, such as roadside barriers, etc. Drive safely at all times and use the exterior and rear-view mirrors to avoid accidents.

The radar sensors may be impaired by rain, snow, or road spray. This may affect the system's ability to reliably detect a vehicle/object within the blind spot.


AWARNING

The driver should not assume that the BSM will correct errors of judgement in driving.

NOTICE

Do not attach stickers or objects to the rear bumpers, that may interfere with the radar sensors.


Note: Make sure that the warning indicators in the exterior mirrors are not obscured by stickers or other objects.



E149545

The Blind Spot Monitor (BSM) system monitors a zone that covers the area adjacent to the vehicle, that is not easily visible by the driver and is designed to help identify any object passing the vehicle.

The system uses a radar on each side of the vehicle to help identify any passing vehicle/object within the blind spot area of the vehicle, while disregarding other objects which may be stationary or traveling in the opposite direction, etc.



E149576